VERSYS-X 300 Motorcycle

OWNER'S MANUAL

A Read this manual carefully. It contains safety information.



AWARNING

Operating, servicing and maintaining a passenger vehicle or off-road vehicle can expose you to chemicals including engine exhaust, carbon monoxide, phthalates, and lead, which are known to the State of California to cause cancer and birth defects or other reproductive harm. To minimize exposure, avoid breathing exhaust, do not idle the engine except as necessary, service your vehicle in a well-ventilated area and wear gloves or wash your hands frequently when servicing your vehicle. For more information go to www.P65warnings.ca.gov/passenger-vehicle.

Quick Reference Guide

This Quick Reference Guide will assist you in finding the information you're looking for.

SAFETY INFORMATION

GENERAL INFORMATION

HOW TO RIDE THE MOTORCYCLE

MAINTENANCE AND ADJUSTMENT

APPENDIX

MAINTENANCE RECORD

A Table of Contents is included after the Foreword.

Whenever you see the symbols shown below, heed their instructions! Always follow safe operating and maintenance practices.

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

NOTICE

NOTICE is used to address practices not related to personal injury.

NOTE

 NOTE indicates information that may help or guide you in the operation or service of the vehicle.

NOTICE

THIS PRODUCT HAS BEEN MANUFACTURED FOR USE IN A REASONABLE AND PRUDENT MANNER BY A QUALIFIED OP-ERATOR AND AS A VEHICLE ONLY.

Foreword

Congratulations on your purchase of a new Kawasaki motorcycle. Your new motorcycle is the product of Kawasaki's advanced engineering, exhaustive testing, and continuous striving for superior reliability, safety and performance.

Please read this Owner's Manual carefully before riding so that you will be thoroughly familiar with the proper operation of your motorcycle's controls, its features, capabilities, and limitations. This manual offers many safe riding tips, but its purpose is not to provide instruction in all the techniques and skills required to ride a motorcycle safely. Kawasaki strongly recommends that all operators of this vehicle enroll in a motorcycle rider training program to attain awareness of the mental and physical requirements necessary for safe motorcycle operation.

To ensure a long, trouble-free life for your motorcycle, give it the proper care and maintenance described in this manual. For those who would like more detailed information on their Kawasaki Motorcycle, a Service Manual is available for purchase from any authorized Kawasaki motorcycle dealer. The Service Manual contains detailed disassembly and maintenance information. Those who plan to do their own work should, of course, be competent mechanics and possess the special tools described in the Service Manual.

Keep this Owner's Manual aboard your motorcycle at all times so that you can refer to it whenever you need information.

This manual should be considered a permanent part of the motorcycle and should remain with the motorcycle when it is sold.

All rights reserved. No part of this publication may be reproduced without our prior written permission.

This publication includes the latest information available at the time of printing. However, there may be minor differences between the actual product and illustrations and text in this manual.

All products are subject to change without prior notice or obligation.

KAWASAKI HEAVY INDUSTRIES, LTD. Motorcycle & Engine Company

© 2018 Kawasaki Heavy Industries, Ltd.

Jun. 15, 2018. (1)

Emission Control Information

To protect the environment in which we all live, Kawasaki has incorporated crankcase emission (1) and exhaust emission (2) control systems in compliance with applicable regulations of the United States Environmental Protection Agency and California Air Resources Board. Additionally, Kawasaki has incorporated an evaporative emission control system (3) in compliance with applicable regulations of the United States Environmental Protection Agency and California Air Resources Board.

1. Crankcase Emission Control System

This system eliminates the release of crankcase vapors into the atmosphere. Instead, the vapors are routed through an oil separator to the intake side of the engine. While the engine is operating, the vapors are drawn into the combustion chamber, where they are burned along with the fuel and air supplied by the fuel injection system.

2. Exhaust Emission Control System

This system reduces the amount of pollutants discharged into the atmosphere by the exhaust of this motorcycle. The fuel, ignition and exhaust systems of this motorcycle have been carefully designed and constructed to ensure an efficient engine with low exhaust pollutant levels. The exhaust system of this model motorcycle includes a catalytic converter system.

3. Evaporative Emission Control System

The evaporative emission control system for this vehicle consists of low permeation fuel hoses and fuel tank.

3. Evaporative Emission Control System (California)

Vapors caused by fuel evaporation in the fuel system are not vented into the atmosphere. Instead, fuel vapors are routed into the running engine to be burned, or stored in a canister when the engine is stopped.

High Altitude Performance Adjustment Information

High Altitude adjustment is not required.

Proper maintenance is necessary to ensure that your motorcycle will continue to have low emission levels. This Owner's Manual contains those maintenance recommendations for your motorcycle. Those items identified by the Periodic Maintenance Chart are necessary to ensure compliance with the applicable standards.

As the owner of this motorcycle, you have the responsibility to make sure that the recommended maintenance is carried out according to the instructions in this Owner's Manual at your own expense.

The Kawasaki Limited Emission Control System Warranty requires that you return your motorcycle to an authorized Kawasaki dealer for remedy under warranty. Please read the warranty carefully, and keep it valid by complying with the owner's obligations it contains.

You should keep a maintenance record for your motorcycle. To assist you in keeping this record, we have provided space on pages 171 through 174 of this manual where an authorized Kawasaki dealer, or someone equally competent, can record the maintenance. You should also retain copies of maintenance work orders, bills, etc., as verification of this maintenance.

Tampering With Noise Control System Prohibited

Federal law prohibits the following acts or the causing thereof: (1) the removal or rendering inoperative by any person other than for purposes of maintenance, repair, or replacement, of any device or element of design incorporated into any new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use, or (2) the use of the vehicle after such device or element of design has been removed or rendered inoperative by any person.

Among those acts presumed to constitute tampering are the acts listed below:

- * Replacement of the original exhaust system or muffler with a component not in compliance with Federal regulations.
- * Removal of the muffler(s) or any internal portion of the muffler(s).
- * Removal of the air box or air box cover.
- * Modifications to the muffler(s) or air intake system by cutting, drilling, or other means if such modifications result in increased noise levels.

TABLE OF CONTENTS

SAFETY INFORMATION	15
Read Owner's Manual	15
Training	15
Daily Checks and Periodic	
Maintenance	15
Loading and Accessories	
Information	16
Passenger	17
Baggage and Luggage	18
Accessories	18
Other Load	19
If You are Involved in an Accident	19
Safe Operation	20
Carbon Monoxide Hazard	20
Fueling	21
Never Ride with Drugs or Alcohol.	21
Protective Gear and Clothing	21
Safe Riding Techniques	22
Additional Considerations for High	
Speed Operation	25

GENERAL INFORMATION	27
Specifications	27
Serial Number Locations	31
Location of Labels	32
Location of Parts	41
Meter Instruments	44
Indicators	45
Speedometer/Tachometer	52
Coolant Temperature Gauge	53
Display Setting	54
Clock	60
Features	61
Keys	64
Ignition Switch/Steering Lock	64
Right Handlebar Switches	66
Left Handlebar Switches	67
Fuel	68
Fuel Requirements	68
Filling the Tank	71
Side Stand	74

Seat	75
Rear Carrier/Tie Hooks	76
Tool Kit/Storage Compartments	78
Helmet Hooks	79
Electrical Accessory Connectors	80
Rear View Mirrors	81
Event Data Recorder	82
HOW TO RIDE THE MOTORCYCLE .	84
Break-In	84
Starting the Engine	85
Moving Off	87
Shifting Gears	88
Braking	89
Anti-lock Brake System (ABS)	91
Stopping the Engine	93
Stopping the Motorcycle in an	
Emergency	93
Parking	94
MAINTENANCE AND ADJUSTMENT	96
Daily Checks	98
Periodic Maintenance	101
Engine Oil	106
Coolant	113

Air Cleaner 11	5
Throttle Control System 11	9
Idle Speed 12	21
Clutch 12	22
Drive Chain 12	24
Brakes 12	28
Brake Light Switches 13	31
Suspension System 13	34
Front Fork 13	34
Rear Shock Absorber 13	34
Setting Table 13	37
Wheels 13	8
Battery 14	1
Headlight 14	5
Fuses 14	8
General Lubrication 14	9
Cleaning 15	60
General Precautions 15	60
Where to be Careful 15	54
Washing Your Vehicle 15	55
APPENDIX	57
Storage 15	57
Troubleshooting Guide 16	60

Your Warranty/Owner Satisfaction ... 165 Environmental Protection 170 MAINTENANCE RECORD 171

Read Owner's Manual

Read this Owner's Manual carefully before riding so that you will be thoroughly familiar with the proper operation of your motorcycle's controls, its features, capabilities, and limitations. This manual offers many safe riding tips, but its purpose is not to provide instruction in all of the techniques and skills required to ride a motorcycle safely.

Daily Checks and Periodic Maintenance

It is important to keep your motorcycle properly maintained and in safe riding condition. Inspect your motorcycle before every ride and carry out all periodic maintenance. See the Daily Checks section and the Periodic Maintenance section in the MAINTENANCE AND ADJUSTMENT chapter for more information.

Training

Kawasaki strongly recommends that all operators of this vehicle complete a suitable motorcycle rider training program to learn the proper skills and techniques necessary for safe motorcycle operation.

Failure to perform these checks or to correct a problem before operation may result in serious damage or an accident. Always perform daily checks before operation.

To ensure your motorcycle is serviced using the latest servicing information, it is recommended that an authorized Kawasaki Dealer performs the periodic maintenance as directed in the Owner's Manual.

If you notice any irregular operating condition, have your motorcycle thoroughly checked at an authorized Kawasaki dealer as soon as possible.

Loading and Accessories Information

Incorrect loading, improper installation or use of accessories, or modification of your motorcycle may result in an unsafe riding condition. Before you ride the motorcycle, make sure it is not overloaded and that you have followed these instructions.

Maximum Load

Weight of rider, passenger, baggage, and accessories must not exceed 180 kg (397 lb).

With the exception of genuine Kawasaki Parts and Accessories, Kawasaki has no control over the design or application of accessories. In some cases, improper installation or use of accessories, or motorcycle modification, will void the motorcycle warranty; can negatively affect performance, stability and safety; and can even be illegal.

In selecting and using accessories, and in loading the motorcycle, you are personally responsible for your own safety and the safety of other persons involved.

NOTE

O Kawasaki Parts and Accessories have been specially designed for use on Kawasaki motorcycles. We strongly recommend that all parts and accessories you add to your motorcycle be genuine Kawasaki components.

Because a motorcycle is sensitive to changes in weight and aerodynamic forces, you must take extreme care in carrying cargo, passengers and/or in fitting additional accessories. The following general guidelines have been prepared to assist you in making your determinations.

Passenger

- 1. Never carry more than one passenger.
- 2. The passenger should only sit on the pillion.
- 3. Any passenger should be thoroughly familiar with motorcycle operation. The passenger can affect control of the motorcycle by improper positioning during cornering and sudden movements. It is important that the passenger sits still while the motorcycle is in motion and not interfere with the operation of the motorcycle. Do not carry animals on your motorcycle.

4. Do not carry passengers unless passenger footpegs are installed. Instruct any passenger before riding to keep his or her feet on the passenger footpegs and hold on to the operator or grab rail. Do not carry a passenger unless he or she is tall enough to reach the footpegs with their feet.

Baggage and Luggage

- All baggage should be carried as low as possible to reduce the effect on the motorcycle's center of gravity. Baggage weight should also be distributed equally on both sides of the motorcycle. Avoid carrying baggage that extends beyond the rear of the motorcycle.
- 2. Baggage should be securely attached. Make sure that the baggage

will not move around while you are riding. Recheck baggage security as often as possible (not while the motorcycle is in motion) and adjust as necessary.

3. Do not carry heavy or bulky items on a luggage rack. It is designed for light items, and overloading can affect handling due to changes in weight distribution and aerodynamic forces.

Accessories

 Do not install accessories or carry baggage that impairs the performance of the motorcycle. Make sure that you have not adversely affected any lighting components, road clearance, banking capability (i.e., lean angle), control operation, wheel travel, front fork movement, or any other aspects of the motorcycle's operation.

- 2. Weight attached to the handlebars or front fork will increase the mass of the steering assembly and can result in an unsafe riding condition.
- 3. Fairings, windshields, backrests, and other large items have the capability of adversely affecting stability and handling of the motorcycle, not only due to their weight, but also due to the aerodynamic force acting on these surfaces while the motorcycle is in operation. Poorly designed or installed items can result in an unsafe riding condition.

Other Load

1. This motorcycle is not intended to be equipped with a sidecar or to be used to tow any trailers or other vehicles. Kawasaki does not manufacture sidecars or trailers for motorcycles and cannot predict the effects of such accessories on handling or stability, but can only warn that the effects can be adverse and that Kawasaki cannot assume responsibility for the results of such unintended use of the motorcycle.

2. Furthermore, any adverse effects on motorcycle components caused by the use of such accessories will not be remedied under warranty.

If You are Involved in an Accident

Make sure of your own safety first. Determine the severity of any injuries and call for emergency assistance if needed. Always follow applicable laws

and regulations if any other person, vehicle or property is involved.

Do not attempt to continue riding without first evaluating your motorcycle's condition. Inspect for fluid leaks, check critical nuts and bolts, and check the handlebars, control levers, brakes, and wheels for damage and proper function. Ride slowly and cautiously - your motorcycle may have suffered damage that is not immediately apparent. Have your motorcycle thoroughly checked at a Kawasaki dealer as soon as possible.

Carbon Monoxide Hazard

A DANGER

Exhaust gas contains carbon monoxide, a colorless, odorless poisonous gas. Inhaling carbon monoxide can cause serious brain injury or death. DO NOT run the engine in enclosed areas. Operate only in a well-ventilated area.

Safe Operation

The following should be carefully observed for safe and effective vehicle operation.

Fueling

Gasoline is extremely flammable and can be explosive under certain conditions. To avoid a possible fire or explosion, turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Never Ride with Drugs or Alcohol

Alcohol and drugs impair your judgment and reaction time. Never consume alcohol or drugs before or while riding motorcycles.

Protective Gear and Clothing

Helmet

Kawasaki strongly recommends both the operator and passenger wear a DOT-approved helmet even if this is not a legal requirement.

- Make sure that your helmet fits correctly and is properly fastened.
- Choose a motorcycle helmet that meets DOT safety standards. Ask your motorcycle dealer to advise you if necessary.

Eye Protection

Always use eye protection. If your helmet does not have a visor installed, wear goggles.

Gloves

Wear gloves which have suitable protection for your hands, especially against abrasion.

Clothing

Wear the riding wear which have protectors for each parts of the body (chest, shoulders, back, elbows and knees, etc.) as much as possible, or wear protectors for them.

- Always wear a long-sleeved jacket and long trousers which are abrasion resistant and keep you warm.
- Wear clothing that allows freedom of movement.
- Avoid wearing clothes which have loose cuffs or other fastenings which

could interfere with the controls of your motorcycle.

- Wear bright, highly visible clothing.

Boots

Wear proper protective boots that fit properly and do not interfere with gear shifting or braking.

Safe Riding Techniques

Keep Hands on Handlebars

When riding always keep both hands on the handlebars and both feet on the footpegs. Removing your hands from the handlebars or feet from the footpegs while riding can be hazardous. If you remove even one hand or foot, you reduce your ability to control the motorcycle.

Look Over Your Shoulder

Before changing lanes, look over your shoulder to make sure the way is clear. Do not rely solely on the rear view mirror; you may misjudge a vehicle's distance and speed, or you may not see it at all.

Accelerate and Brake Smoothly

In general your actions should be smooth as sudden acceleration, braking or turning may cause loss of control, especially when riding in wet conditions or on loose road surfaces, when the ability to maneuver will be reduced.

Select Correct Gear Speeds

When going up steep slopes, shift to a lower gear so that there is power to spare rather than overloading the engine.

Use Both Front and Rear Brakes

When applying the brakes, use both the front and rear brakes. Applying only one brake for sudden braking may cause the motorcycle to skid and lose control.

Use Engine Brake

When going down long slopes, help control vehicle speed by closing the throttle so that the engine can act as an auxiliary brake. Use the front and rear brakes for primary braking.

Riding in Wet Conditions

Rely more on the throttle to control vehicle speed and less on the front and rear brakes. The throttle should also be used judiciously to avoid skidding the rear wheel from too rapid acceleration or deceleration.

Braking performance is also reduced in wet conditions. Carefully ride at a

slow speed and apply the brakes several times to help dry and restores them to normal operating performance.

Lubricate the drive chain after wet -weather riding to prevent rust and corrosion.

Ride Prudently

Riding at the proper speed and avoiding unnecessarily fast acceleration are important not only for safety and low fuel consumption but also for long vehicle life and quieter operation.

Riding on Rough Roads

Exercise caution, slow down, and grip the fuel tank with the knees for better stability.

Acceleration

When quick acceleration is necessary to pass another vehicle, shift to a lower gear to obtain the necessary power.

Downshifting

To avoid engine damage and rear wheel lock-up do not downshift at high rpm.

Avoid Unnecessary Weaving

Unnecessary weaving jeopardizes the safety of both the rider and other motorists.

Additional Considerations for High Speed Operation

A WARNING

Handling characteristics of a motorcycle at high speeds may vary from those you are familiar with at legal highway speeds. Do not attempt high speed operation unless you have received sufficient training and have the required skills.

Do not operate at high speeds on public roads.

Brakes

The importance of the brakes, especially during high speed operation, cannot be overemphasized. Check to

see that they are correctly adjusted and functioning properly.

Steering

Looseness in the steering can cause loss of control. Check to see that the handlebars turns freely but has no play.

Tires

High speed operation is hard on tires, and good tires are crucial for safe riding. Examine their overall condition, inflate them to the proper pressure, and check the wheel balance.

Fuel

Have sufficient fuel for the high fuel consumption during high speed operation.

Engine Oil

To avoid engine seizure and resulting loss of control, make sure that the oil level is at the upper level line.

Coolant

To avoid overheating, check that the coolant level is at the upper level line.

Electrical Equipment

Make sure that the headlight, tail/brake light, turn signals, horn, etc., all work properly.

Miscellaneous

Make sure that all nuts and bolts are tight and that all safety related parts are in good condition.

Specifications

PERFORMANCE

Minimum Turning Radius	2.5 m (8.2 ft)
DIMENSIONS	
Overall Length	2 170 mm (85.43 in.)
Overall Width	860 mm (33.9 in.)
Overall Height	1 390 mm (54.72 in.)
Wheelbase	1 450 mm (57.09 in.)
Road Clearance	180 mm (7.09 in.)
Curb Mass:	
KLE300B	173 kg (381 lb)
KLE300C	175 kg (386 lb)
ENGINE	
Туре	DOHC, 2-cylinder, 4-stroke, liquid-cooled
Displacement	296 cm³ (18.1 cu in.)

Bore × Stroke		62.0 × 49.0 mm (2.44 × 1.93 in.)	
Compression Ratio		10.6:1	
Starting System		Electric starter	
Cylinder Numberi	ng Method	Left to right, 1-2	
Firing Order		1-2	
Fuel System		FI (Fuel Injection)	
Ignition System		Battery and coil (transistorized ignition)	
Ignition Timing (Electronically advanced)		10° BTDC @1 300 r/min (rpm) ~ 35° BTDC @4 000 r/min (rpm)	
Spark Plug:	Туре	NGK CR8E	
	Gap	0.7 ~ 0.8 mm (0.028 ~ 0.031 in.)	
Lubrication Syste	m	Forced lubrication (wet sump)	
Engine Oil:	Туре	API SG, SH, SJ, SL, or SM with JASO MA, MA1 or MA2	
	Viscosity	SAE 10W-40	
	Capacity	2.4 L (2.5 US qt)	
Coolant Capacity		1.5 L (1.6 US qt)	

TRANSMISSION

Transmission Typ	be	6-speed, constant mesh, return shift	
Clutch Type		Wet, multi disc	
Driving System		Chain drive	
Primary Reduction Ratio		3.087 (71/23)	
Final Reduction Ratio		3.286 (46/14)	
Overall Drive Ratio		8.694 (Top gear)	
Gear Ratio:	1st	2.714 (38/14)	
	2nd	1.789 (34/19)	
	3rd	1.409 (31/22)	
	4th	1.160 (29/25)	
	5th	1.000 (27/27)	
	6th	0.857 (24/28)	
FRAME			
Caster		24.3°	
Trail		108 mm (4.25 in.)	

Tire Size:	Front	100/90-19M/C 57S
	Rear	130/80-17M/C 65S
Rim Size:	Front	19 × 2.15
	Rear	17M/C × MT3.00
Fuel Tank Capacit	y	17 L (4.5 US gal)
Brake Fluid:	Front	DOT3 or 4
	Rear	DOT4
ELECTRICAL EQU	IPMENT	
Battery		12 V 8 Ah (10 HR)
Headlight:	High Beam	12 V 60 W
	Low Beam	12 V 55 W
Brake/Tail Light		12 V 21/5 W

Specifications are subject to change without notice.

Serial Number Locations

The engine and frame serial numbers are used to register the motorcycle. They are the only means of identifying your particular machine from others of the same model type. These serial numbers may be needed by your dealer when ordering parts. In the event of theft, the investigating authorities will require both numbers as well as the model type and any peculiar features of your machine that can help them identify it.

Engine No.



A. Engine Number

Frame No.



A. Frame Number


Location of Labels

All warning labels which are on your vehicle are repeated here. Read labels on your vehicle and understand them thoroughly. They contain information which is important for your safety and the safety of anyone else who may operate your vehicle. Therefore, it is very important that all warning labels be on your vehicle in the locations shown. If any label is missing, damaged, or worn, get a replacement from your Kawasaki dealer and install it in the correct position.


NOTE


 The sample warning labels in this section have part numbers to help


- you and your dealer obtain the correct replacement.
- Refer to the actual vehicle label for model specific data grayed out in the illustration.




1. Brake Fluid (Front)








- Brake Fluid (Rear)
 Battery Poison/Danger
 Rear Shock Absorber Warning





- Radiator Cap Danger
 Tire and Load Data
 Important Drive Chain Information
 Noise Emission Control Information
- *9. Fuel Level
- *: only on California model





- 10. Weight and Manufacture *11. Vacuum Hose Routing Diagram 12. Vehicle Emission Control Information 13. Rear Carrier Load Limit Warning

 - *: only on California model

1)







TE03879DN9 C

3)

2)

4)

🔺 WARNING

This unit contains high pressure nitrogen gas.

Wishandling can cause explosion.

• Do not incinerate,puncture or open.

🔺 AVERTISSEMENT

Cette unité contient de l'azote à haute pression. Une mauvaise manipulation peut entraÎner d'explosion. ● Ne pas brûler ni perforer ni ouvrir.

▲ 警告

高圧窒素ガス入りです。 取り扱いを誤ると爆発する恐れがあります。

● 火中への投入、穴あけ、分解はしないてください。

5)



6)

			er inflation or excess tires or overloading o	
	Owner's M	anual for TIRE /	using serious bodily in additional information AND LOAD DA Szeli Hale Type	ı. [.]
Front	in to 180 kg load	200 169	RC 100/90-194/C 575 GP-210F	1 mm (0.04 in)
Rear	(397 lbs)	225 128 225 14/0 1 , 32 mil	IRC 130/80-176/C 665 GP-2108	Ber to 130 km/h 60 4440 2 ma 0.28 m Over 120 km/h 80 4440 3 en 042 m

TE03842E S

7)

CHA'N 'NECRMATICN Drive chain slack should be checked potore each rice and adjusted if outside of normal solusiment range (25-35 mm, 1.0-1.4 in). le check sieck, measure plack midway Never between the sprockets while the ogener. motorevels is on the side stand or center stand heat See Cyner's Manuel for additional drive chain information. flow 56033-1384 in hard starting and ensine hesitation. TE03849E S 8) 56071-0158 TE03142C S MOTORCYCLE NOISE EMISSION CONTRO L N E 10) THIS KXXXX MOTORCYCLE MEETS FPA NOISE EM SSION REQUIREMENTS BY THE FEDERAL TEST PROCEDURE. MODIFICATIONS WHICH CAUSE THIS MOTORCYCLE TO NFD. BY KAWASAKI HEAVY INDUSTRIES, LTD. EXCEED FEDERAL NOISE STANDARDS ARE PROH B TED DATE: THIS VEHICLE CONFORMS BY FEDERAL LAW. SEE OWNER'S MANUAL. (Recommendation) TO ALL APP F FEDERAL MOTOR VEHICLE MODEL SPECIFIC CODE: SAFETY FEFECT ON THE DATE SEE VEHICLE IDENTIFICATION NUMBER ON STEERING HEAD OF MANUEA SI ABOVE. GVW NOISE LIMIT/CLOSING RPM: CBA/ CON RPM GAWR F 🖂 LBS TIRE. TE03304D S GAWR R 🗠 LBS ¥١ TIRE, XXXXXXX 100

9) only on California model


 \sim

NOTOR CYCLE

TE03442DN9 C

WADE IN THAILAND

11) only on California model





12) only on California model



12)




TE03269E S

13)

🔬 WARNING	DO NOT EXCEED REAR CARRIER	MAXIMUM LOAD REAR CARRIER
●Read your Owner's Manual	WITH SADDLEBAGS	WITHOUT SADDLEBAGS
for more detoiled and complete instruction.	3 kg(6.6 lbs)	6 kg(13 lbs)
 Do not exceed the total pay and tire information label. 	load limit shown in	n the Owners Manual
●Do not install top case w	hen saddlebags are	equipped on your
motorcycle. Overloading m control and an accident r	ay cause adverse h esultinn in seriou	andling, loss of is iniury or death.
Do not exceed the vehicle	speed of 130 km/h(80 mph) when
corrying a passenger and/c to road or weather conditi		
to compensate for added we	right and other con	ditions may result
<u>in a loss of control and s</u>	ubsequent occident)


56071-0736

Location of Parts




- 1. Rear View Mirrors
- 2. Starter Lockout Switch
- 3. Meter Instrument
- 4. Brake Fluid Reservoir (Front)
- 5. Clutch Lever

- 6. Left Handlebar Switches
- Ignition Switch/Steering Lock
 Right Handlebar Switches
 Throttle Grip
 Front Brake Lever



- 1. Headlight
- 2. Turn Signal Lights
- 3. Fuel Tank
- 4. Idle Adjusting Screw
- 5. Air Cleaner
- 6. Spring Preload Adjuster
- 7. Seat
- 8. Seat Lock
- 9. Tool Kit
- 10. Grab Rail

- 11. Rear Carrier
- 12. Front Fork
- 13. Radiator
- 14. Shift Pedal
- 15. Side Stand Switch
- 16. Side Stand
- 17. Rear Shock Absorber
- 18. Drive Chain
- 19. Chain Adjuster



- 1. License Plate Light
- 2. Tail/Brake Light
- 3. Fuse Box
- 4. Brake Fluid Reservoir (Rear)
- 5. Battery


- 6. Rear Brake Light Switch
- 7. Spark Plugs
- 8. Fuel Tank Cap 9. Coolant Reserve Tank
- 10. Brake Discs

- 11. Brake Calipers
- 12. Swingarm
- 13. Muffler
- 14. Oil Level Inspection Window
- 15. Brake Pedal

Meter Instruments

- 1. Lower Meter Button
- 2. Upper Meter Button
- 3. Tachometer
- 4. Multifunction Meter
- 5. Gear Position Indicator
- 6. Fuel Gauge
- 7. Multifunction Display
 - Odometer
 - Trip Meter A/B
- 8. Speedometer
- 9. Economical Riding Indicator
- 10. Multifunction Display
 - Current Mileage/Average Mileage/Cruising Range
- 11. Coolant Temperature Gauge
- 12. Clock

When the ignition switch is turned on, all LCD functions are shown for a few seconds, then the multifunction meter turns to operational mode.



Indicators

- 1. (IIII) ABS Indicator (Yellow) (ABS model)
- 2. N Neutral Indicator (Green)
- 3. ID High Beam Indicator (Blue)
- 4. 😋 Engine Warning Indicator (Yellow)
- 5. Left Turn Signal Indicator (Green)
- 6.

 Right Turn Signal Indicator (Green)
- 7. 📦 Fuel Level Warning Indicator
- 8. 🛅 Battery Warning Indicator
- 9. **L** Coolant Temperature Warning Indicator
- 10. Mrs Oil Pressure Warning Indicator
- 11. F Warning Indicator (Red)



Indicator Initial Operation



When the ignition switch is turned on, all indicators go on/off as shown in the table. If any indicator does not operate as shown, have it checked by an authorized Kawasaki dealer.

ON	Dq	6	Indicators
		•	₹ D
			ان ا از
-			■ + +

ON: When ignition switch is turned on.

- I : After a few seconds
- I When engine starts.
 - $\hfill\square$: Goes on.
 - : Goes off.
 - *: () goes off shorty after the motorcycle starts moving.

When Warning Indicators Go On or Blink

When warning indicators appear, there could be a problem with vehicle function. Follow actions in the table after stopping the vehicle in a safe place.

*: The numbers in this column corresponds to reference numbers on page 45.

*No.	Indi- cators	Status	Actions
1	(485)	ON*1	The ABS has malfunctioned. ABS will not work but conventional brakes function. Have the ABS checked by an authorized Kawasaki dealer.
4	Ō	ON	The DFI system has malfunctioned. Have it checked by an authorized Kawasaki dealer.
11 8		ON	These indicators go on if the battery voltage is less than 11.0 V or more than 16.0 V. If the voltage is less than 11.0 V, charge the battery. If the voltage is more than 16.0 V, or if indicators still go on after charging the battery, have the battery and/or charging system checked by an authorized Kawasaki dealer.

*No.	Indi- cators	Status	Actions
11 10	7	ON	These indicators go on whenever the oil pressure is dangerously low or the ignition switch is in the "ON" position with the engine not running. If these indicators go on when the engine speed is above idle, stop the engine immediately and check the engine oil level. If the amount of engine oil is insufficient, add engine oil. If the oil level is good, have the engine checked by an authorized Kawasaki dealer.
11 9		ON	These indicators go on whenever the coolant temperature rises to about 115°C (239°F). Refer to the Coolant Temperature Gauge section for more information and follow instructions in it.

*No.	Indi- cators	Status	Actions
7	P	Blink	The lowest segment and fuel level warning indicator blink in the multifunction display when approximately 3.0 L (0.79 US gal) of usable fuel remains. Refuel at the earliest opportunity. If the vehicle is on the side stand, the warning indicator cannot estimate the amount of fuel in the tank. Stand the vehicle upright to check the fuel level.
		Blink (including all segments)	The fuel level warning system has malfunctioned. Have the fuel level warning system checked by an authorized Kawasaki dealer.

*1: ABS indicator may go on:

O After continuous riding on a rough road.


- OWhen the engine is started with the stand raised and the transmission engaged, and the rear wheel turns.
- OWhen accelerating so abruptly that the front wheel leaves the ground.
- OWhen the ABS has been subjected to strong electrical interference.
- OWhen tire pressure is abnormal. Adjust tire pressure.
- OWhen a tire different in size from the standard size is being used. Replace with standard size.
- OWhen the wheel is deformed. Replace the wheel.

If this happens, first turn the ignition switch off, and then back on, and ride the motorcycle at 5 km/h (3.1 mph) or more. The ABS indicator should then go off. If it does not, have the ABS checked by an authorized Kawasaki dealer.

Other Indicators

*No.	Indicators	Status	
2	N When the transmission is in neutral, this indicator goes on.		
3		When the headlight is on high beam, this indicator goes on.	
5	ŧ	When the turn signal switch is pushed to the left, this indicator blinks.	
6	+	When the turn signal switch is pushed to the right, this indicator blinks.	

Speedometer/Tachometer



- A. Tachometer
- **B.** Speedometer
- C. Red Zone

Speedometer

The speedometer is digital and can be set for km/h or mph.

The unit setting can be changed according to local regulations. Make sure the unit setting (km/h or mph) is correctly displayed before riding.

Refer to the Unit Setting in the Display Setting section.

Tachometer

The tachometer shows the engine speed in revolutions per minute (r/min, rpm).


NOTICE

Engine speed should not be allowed to enter the red zone; operation in the red zone will overstress the engine and may cause serious engine damage.

When the ignition switch is turned on, the tachometer needle momentarily sweeps from the minimum to the maximum reading, then back the minimum reading to check its operation. If the tachometer does not operate correctly, have it checked by an authorized Kawasaki dealer.

Coolant Temperature Gauge


The coolant temperature gauge indicates temperature of the engine coolant by the number of segments displayed.



A. Segments B. H (Hot) C. C (Cold)

If the coolant temperature rises to above 115°C (239°F), all segments go on, and the warning indicator and coolant temperature warning indicator go on. This warns the operator that the coolant temperature is high. Stop the engine and check the coolant level in the reserve tank after the engine cools down. If the amount of the coolant is

insufficient, add coolant to the reserve tank. If the coolant level is good, have the cooling system checked by an authorized Kawasaki dealer.



A. Warning Indicator (Red) B. Coolant Temperature Warning Indicator

NOTICE

Stop the engine if the warning indicator and coolant temperature warning indicator go on. Prolonged engine operation will result in severe engine damage from overheating.

Display Setting

Multifunction Display


For safety, do not operate the meter buttons while riding the motorcycle.

 Push the upper meter button or lower meter button to select the display

modes. The display modes can be shifted in the following order.

NOTE

 The multifunction display is displayed in the unit depending on the unit mode setting.



- A. Upper Meter Button
- B. Lower Meter Button
- C. Flow when pushing upper meter button
- D. Flow when pushing lower meter button

Odometer

The odometer shows the total distance. This meter cannot be reset.



NOTE

• When the figures come to 999999, the display is stopped and locked.

Trip Meter



To reset the trip meter:

• Push the upper meter button to select the trip meter A or B.

• Push the upper meter button and hold it in until the display turns to 0.0.

NOTE

 When the trip meter reaches 9999.9 while riding, the meter resets to 0.0 and continues counting.

Current Mileage

The current mileage display is renewed every 4 seconds.



NOTE

 ○ When the ignition switch is turned on, the numerical value shows "- -.-." After a few seconds of riding the numerical value is displayed.

Average Mileage

This display shows the average fuel consumption from the reset. The average mileage display is renewed every 5 seconds.



To reset the average mileage:

• Push the lower meter button and hold it in until the average mileage values resets to "--. -."

NOTE

 ○ When the battery is disconnected, the average mileage resets to "--.-."
 ○ After resetting the average mileage, the numerical value is not displayed until the vehicle has travelled 100 m (328 ft).

Cruising Range

This display shows the cruising range by numerical value, and indicates the cruising range from the remaining fuel in the fuel tank. This cruising range display is renewed every 20 seconds.




NOTE

- The cruising range value is no longer shown if the fuel level gets too low after the fuel level warning indicator starts blinking.
- To recover the cruising range value display add fuel to at least the level needed for the fuel level warning indicators to stop blinking. The cruising range may still be displayed with


a low fuel level, but it will not be accurate until enough fuel is added to stop the fuel level warning indicator from blinking.

Unit Setting



A. Units


• Display the odometer in the multifunction display. • Push the lower meter button while pushing the upper meter button to select the meter display units. The display units can be shifted in the following order.



Clock

To adjust the clock:

- Push the upper and lower meter buttons and hold them until both the hour and minute displays blink.
- Push the lower meter button and hold it until "12h" or "24h" is appeared on the display.
- Push the upper meter button to select "12h" or "24h."
- Push the lower meter button to select the hour or minute digits.
- Push the upper meter button to adjust the hour or minute digits.
- To finish the clock adjustment, push the upper meter button when both the hour and minute digits blink.



- A. Flow when pushing and holding upper and lower meter buttons
- B. Flow when pushing lower meter button
- C. Flow when pushing upper meter button
- D. Flow when pushing and holding lower meter button

NOTE

○ When the battery is disconnected, the clock is reset to 1:00 ("24h" display: 13:00) and starts working again when the battery is connected.

Features

Economical Riding Indicator

When riding the motorcycle efficiently, the economical riding indicator appears on the multifunction meter to indicate favorable fuel consumption. Monitoring the economical riding indicator can help the rider maximize fuel efficiency.




A. Economical Riding Indicator

Failing to properly observe the road ahead increases the chance of an accident resulting in severe injury or death. Do not concentrate on the economical riding indicator by taking your eyes off the road; observe using peripheral vision.

Fuel Gauge

The fuel in the fuel tank is shown by the number of segments displayed.



A. Segments B. F (Full) C. E (Empty)

NOTE


When the fuel tank is full, all the segments are displayed. As the fuel level in the tank goes down, the segments disappear one by one from F (full) to E (empty).

 When the fuel level warning indicator and bottom segment blink, refer to the "When Warning Indicators Go On or Blink" of Indicators in this chapter.

Gear Position Indicator

This display shows the corresponding gear position when the transmission is shifted. As the transmission is shifted, the corresponding gear position (1st ~ 6th) is shown in this display. When the transmission is in neutral, "N" is displayed, and the neutral indicator goes on.

1	When the transmission is in 1st gear, "1" is displayed.	
2	When the transmission is in 2nd gear, "2" is displayed.	
3	When the transmission is in 3rd gear, "3" is displayed.	
4	When the transmission is in 4th gear, "4" is displayed.	
5	When the transmission is in 5th gear, "5" is displayed.	
6	When the transmission is in 6th gear, "6" is displayed.	




A. Neutral Indicator (Green) B. Gear Position Indicator

NOTE

 If the gear position display in the multifunction meter blinks "-," the transmission is not properly shifted to 1st. Be sure to shift the transmission.

Keys

You will need the key number or spare key to have a duplicate made.




A. Ignition Key B. Key Number Tag C. Key Number

If you lose all keys and the key number, you will need to replace the ignition switch and all other locks operated by that key. Contact your Kawasaki dealer to purchase additional spare keys.

Ignition Switch/Steering Lock

This is a four-position, key-operated switch.

The key can be removed when it is in the "OFF" or "LOCK" position.



 Engine can be started. All electrical equipment can be used. Key cannot be removed. 	
 Engine off. Electrical equipment is off. Key can be removed. 	
LOCK Steering locked. • Engine off. • Electrical equipment is off. • Key can be removed.	

For Locking:

- 1. Turn the handlebars fully to the left.
- 2. Push the key down in the "OFF" position and turn it to "LOCK."




Turning the ignition switch to the "OFF" position while riding the motorcycle shuts down the entire electrical system (headlight, brake light, turn signal light, etc.) and the engine will stop, which could cause an accident resulting in severe injury or death. Never operate the ignition switch while riding the motorcycle; only operate it when the motorcycle is at a standstill.

NOTE

- The tail, city and license plate lights are on whenever the ignition key is in the "ON" position. The headlight goes on when the starter button is released after starting the engine.
- Do not leave the ignition switch at the "ON" position for an extended time

with the engine stopped, or the battery may become totally discharged. O Do not leave the hazard lights switched on for a long time without the engine running or the battery will become discharged.

Right Handlebar Switches



A. Starter Button B. Engine Stop Switch

Starter Button Ø

Refer to the Starting the Engine section in the HOW TO RIDE THE MOTORCYCLE chapter for starting instructions.

Engine Stop Switch

To stop the engine in an emergency, move the engine stop switch to the


× position.

Ordinarily, the engine stop switch must be in the O position for the motorcycle to operate.

NOTE

- Ordinarily, the ignition switch should be used to stop the engine.
- Although the engine stop switch stops the engine, it does not turn off all the electrical circuits and eventually the battery will be discharged.

Left Handlebar Switches



- A. Dimmer Switch
- **B. Turn Signal Switch**
- C. Horn Button
- **D. Passing Button**
- E. Hazard Switch

Dimmer Switch

High or low beam can be selected with the dimmer switch. High beam... ≣⊃ (High beam indicator: see Meter Instruments section) Low beam... ₽

NOTE

O Do not allow anything to cover the headlight lens when the headlight is on. If covered, heat can build up in the headlight lens causing lens discoloration or melting, as well as damage to the item covering the lens.

Turn Signal Switch

When the turn signal switch is turned to the left (\Leftrightarrow) or right (\Leftrightarrow) the corresponding turn signal lights and turn signal indicator blinks. To cancel the turn signal, push the switch in.

Horn Button 🗁

When the horn button is pushed, the horn sounds.

Passing Button PASS

The high beam turns on only while the passing button is pushed.

Hazard Switch 💩

Push in the hazard switch with the ignition switch in the "ON" position. All the turn signal lights and turn signal indicators will blink.

NOTE

 Be careful not to use the hazard lights for an extended period of time, otherwise the battery may become totally discharged.

Fuel

Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns. Turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Fuel Requirements

Use clean, flesh unleaded gasoline with the following conditions.

- Antiknock Index of 87 or more
- Up to 10% of ethanol contained

NOTICE

Use only unleaded gasoline. Never use leaded gasoline. Leaded gasoline significantly reduces the capability of the catalytic converter in the exhaust system.

NOTICE

Use minimum of 87 octane gasoline only to prevent severe engine damage.

NOTICE

If engine "knocking" or "pinging"occurs, use a different brand of gasoline of a higher octane rating. If this condition is allowed to continue it can lead to severe engine damage. Gasoline quality is important. Fuels of low quality or not meeting standard industry specifications may result in unsatisfactory performance. Operating problems that result from the use of poor quality or nonrecommended fuel may not be covered under your warranty.

NOTICE

Avoid using blends of unleaded gasoline and methanol (wood alcohol) whenever possible, and never use "gasohol" containing more than 5% methanol. Fuel system damage and performance problems may result.

NOTE

 Other oxygenates approved for use in unleaded gasoline include TAME (up to 16.7%) and ETBE (up to 17.2%). Fuel containing these oxygenates can also be used in your Kawasaki.

NOTICE

Never use gasoline with an octane rating lower than the minimum specified by Kawasaki. Never use "gasohol" with more than 10% ethanol, or more than 5% methanol.

Gasoline containing methanol must also be blended with cosolvents and corrosion inhibitors. Certain ingredients of gasoline may cause paint fading or damage. Be extra careful not to spill gasoline or gasoline oxygenate blends during refueling. When not operating your

When not operating your Kawasaki for 30 to 60 days, mix a fuel stabilizer (such as STA-BIL) with the gasoline in the fuel tank. Fuel stabilizer additives inhibit oxidation of the fuel which minimizes gummy deposits.

Fuel Type and Octane Rating

Use clean, fresh unleaded gasoline.

The Antiknock Index is posted on service station pumps. The octane rating of a gasoline is a measure of its resistance to detonation or "knocking." The Antiknock Index is an average of the Research Octane Number (RON) and the Motor Octane Number (MON) as shown in the table.

Fuel Type	Unleaded Gasoline
Ethanol Content	E10 or less
Antiknock Index	87 or more

NOTICE

Do not use any fuel that contains more ethanol or other oxygenates than specified for E10 fuel* in this vehicle. Damage to the engine and fuel system, or engine starting and/or performance problems may result from the use of improper fuel.

*E10 means fuel containing up to 10% ethanol.

Filling the Tank

Avoid filling the tank in the rain or where heavy dust is blowing so that the fuel does not get contaminated.

A WARNING

Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns. Turn the ignition switch off. Do not smoke.

Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light. Never fill the tank completely to the top.


If the tank is filled completely to the top, heat may cause the fuel to expand and overflow through the vents in the tank cap.

After refueling, make sure the tank cap is closed securely. If gasoline is spilled on the fuel tank, wipe it off immediately.


NOTICE

California model only: Never fill the tank so the fuel level rises into the filler neck. If the tank is overfilled, heat may cause the fuel to expand and flow into the Evaporative Emission Control System resulting in hard starting, engine hesitation and non-compliance with the emission regulation.

- Lift the key hole cover.
- Insert the ignition key into the fuel tank cap.
- Turn the key clockwise while pushing down the fuel tank cap.



- A. Key Hole Cover
- B. Ignition Key
- C. Fuel Tank Cap
- Open the fuel tank cap.
- Add fuel.



- A. Tank Cap
- B. Fuel Tank
- C. Top Level
- D. Bottom of Filler Neck (Maximum Fuel Level)

NOTE

- Do not exceed the maximum fuel level as shown.
- Push the fuel tank cap down into place with the key inserted.

- The key can be removed by turning counterclockwise to the original position.
- Close the key hole cover.

NOTICE

Never fill the tank completely to the top.

If the tank is filled completely to the top, heat may cause the fuel to expand and overflow through the vents in the tank cap. After refueling, make sure the tank cap is closed securely. If gasoline is spilled on the fuel

NOTE

tank, wipe it off immediately.

 The fuel tank cap cannot be closed without the key inserted, and the key cannot be removed unless the cap is locked properly.

• Do not push on the key to close the cap, or the cap cannot be locked.

Side Stand

Always kick the stand fully up before moving the motorcycle. The engine will stop automatically if the motorcycle is in gear and the clutch is released with the side stand down.

NOTE


- When using the side stand, turn the handlebars to the left.
- Make sure the side stand is down securely before leaving the motorcycle.
- Do not sit on the motorcycle while it is on its side stand.

Seat

The seat can be removed using the ignition key.

Seat Removal


- Insert the ignition key into the seat lock.
- Lift the rear part of the seat while turning the key clockwise.
- Remove the seat backward.
- Remove the ignition key.



A. Ignition Key B. Seat

Seat Installation


- Insert the hooks of the seat under the frame.
- Insert the projection at the rear part of the seat into the latch hole on the frame.
- Push down the rear part of the seat until the lock clicks.



- A. Seat
- B. Hooks
- C. Frames
- **D. Projection**
- E. Latch Hole
- Pull up the front and rear ends of the seat to make sure they are securely locked.

Rear Carrier/Tie Hooks

This motorcycle is equipped with the rear carrier. The tie hooks are located under the rear carrier.



A. Rear Carrier B. Tie Hooks

Overloading the motorcycle with cargo and/or passengers, and/or not balancing the weight of items carried on the rear carrier may cause adverse handling, loss of control and an accident resulting in serious injury or death. Do not carry loads of more than 6 kg (13 lb) on the rear carrier. Do not exceed the total payload limit of 180 kg (397 lb), including rider, passenger, baggage, and accessories. Do not exceed the vehicle speed of 130 km/h (80 mph) when carrying a passenger and/or cargo. Also reduce speed according to road or weather condition, etc. Failure to adjust the speed to compensate for added weight and other conditions may result in a loss of control and subsequent accident.

During installing the saddlebags, follow precautions below.


- Do not carry loads of more than 3 kg (6.6 lb) on the rear carrier.
- Do not install the top case.

Tool Kit/Storage Compartments


The tool kit and storage compartments are located under the seat.

Keep the tool kit in the storage compartment under the compartment cover.

• Push the tab to open the compartment cover.




- A. Compartment Cover (Storage Compartment)
- B. Tab
- C. Push
- D. Open



A. Storage Compartment B. Tool Kit

Helmet Hooks

The Helmets can be secured to the motorcycle using the helmet hooks located under the seat.



A. Helmet Hooks

A WARNING

Riding with helmets attached to the hooks could cause an accident by distracting the operator or interfering with normal vehicle operation. Do not ride the motorcycle with helmets attached to the hooks.

Electrical Accessory Connectors

The electric power of the battery can be used through the electrical accessory connectors.

NOTE

 The electrical accessory connection to the connectors should be done by an authorized Kawasaki dealer.

NOTICE

Do not connect the accessories other than specified accessories.

Accessory Connector


Location	Purpose
Lower of Headlight	Fog Lights
Maximum Current: 1	.3 A



A. Accessory Connector (for Fog Lights)

Accessory Connectors

Location	Purpose	Polar- ity	Wire Color				
Dook of	Acces-	(+)	White/Black				
Headlight	Back of Headlight Socket		Black/Yel- low				
Maximum Current: 1.2 A							



A. Accessory Connectors (for Accessory Socket)

NOTICE

This accessory circuit 5 A fuse for the fog lights and accessory socket. Always install a fuse 5 A or less for the circuit. Do not connect more than 56 W of load to this accessory circuit or the battery may become discharge, even with the engine running.


Rear View Mirrors

Rear View Mirror Adjustment

- Adjust the rear view mirror by slightly moving only the mirror portion of the assembly.
- If the rear visibility cannot be assured by moving the mirror, slide the rubber boot up, and loosen the locknut and turn the stay by hand.

NOTE

- The locknut has left hand threads.
- Tighten the locknut securely.



- A. Rear View Mirror
- B. Stay
- C. Rubber Boot
- D. Locknut

Event Data Recorder

In common with many other vehicle manufacturers, Kawasaki has equipped this motorcycle with an event data recorder (EDR). The purpose of this device is to record data that assists with understanding of how some of the vehicle's systems were performing during a short period of time immediately before and during an accident or similar event involving minor damage. Due to accident variables, all vehicle performance data may not be stored on the EDR.

NOTE

- During normal riding, data is recorded but not saved unless the vehicle is involved in an accident event.
- At no time other than in the event of an accident or similar event involving minor damage is it possible for EDR data to be stored for retrieval.
- Depending on the type of accident event, it is possible that the EDR may not record some or all of the data, or it may not record if the EDR is damaged.

 This device does not collect or store personal data or information (e.g. name, gender, age).

The EDR in this vehicle is designed to record only data that is relevant to the vehicle's running condition at the time of an accident like, but not limited to, vehicle speed, engine crankshaft rotational speed and throttle opening, etc.

This data can help provide a better understanding for both the rider and the manufacturer of how the vehicle was performing at the time of an accident or near accident-like situation.

To access information on an EDR, special equipment and access to the EDR is required. Kawasaki will not share EDR information without obtaining your consent, unless required by government authorities, or acting pursuant to lawful authority.

84 HOW TO RIDE THE MOTORCYCLE HOW TO RIDE THE MOTORCYCLE

NOTICE

This vehicle is designed only for on-road riding including unpaved public roads. It is not designed for use off-road.

Break-In

The first 1 600 km (1 000 mile) that the motorcycle is ridden is designated as the break-in period. If the motorcycle is not used carefully during this period, you may very well end up with a "broken down" instead of a "broken in" motorcycle after a few thousand kilometers.

The following rules should be observed during the break-in period.

• The table shows maximum recommended engine speed during the break-in period.

Distance traveled	Maximum engine speed
0 ~ 800 km (0 ~ 500 mile)	4 000 r/min (rpm)
800 ~ 1 600 km (500 ~ 1 000 mile)	6 000 r/min (rpm)

NOTE

- When operating on public roadways, keep maximum speed under traffic law limits.
- Do not start moving or race the engine immediately after starting it, even if the engine is already warm.

Run the engine for two or three minutes at idle speed to give the oil a chance to work up into all the engine parts.


• Do not race the engine while the transmission is in neutral.

New tires are slippery and may cause loss of control and injury. A break-in period of 160 km (100 miles) is necessary to establish normal tire traction. During break-in, avoid sudden and maximum braking and acceleration, and hard cornering.


In addition to the above, at 1 000 km (600 mile) it is extremely important that the owner has the initial maintenance service performed by an authorized Kawasaki dealer.

Starting the Engine

• Check that the engine stop switch is in the Ω position.



- A. Engine Stop Switch
- B. Starter Button
- Turn the ignition key to "ON" position.
- Make sure the transmission is in neutral.



- A. Neutral Indicator (Green) B. Ignition Switch
- C. "ON" Position

NOTE

○ While the engine is cold, the fast idle system automatically raises the engine idling speed. At this time, the engine warning indicator () may go on if you operate the throttle grip unnecessarily.


- O The motorcycle is equipped with a vehicle-down sensor which causes the engine to stop automatically if the motorcycle falls down. After righting the motorcycle, first turn the ignition key to "OFF" and then back to "ON" before starting the engine.
- Without holding the throttle grip, push the starter button to start the engine.

NOTICE

Do not operate the starter continuously for more than 5 seconds, or the starter will overheat and the battery power will drop temporarily. Wait 15 seconds between each operation of the starter to let it cool and the battery power recover.

NOTE

O The motorcycle is equipped with a starter lockout switch. This switch is designed so that the engine does not start if the transmission is in gear and the side stand is down. However, the engine can be started if the clutch lever is pulled and the side stand is fully up.



A. Clutch Lever B. Starter Lockout Switch

NOTICE

Do not let the engine idle longer than 5 minutes, or engine overheating and damage may occur.

Moving Off

- Check that the side stand is up.
- Pull in the clutch lever.
- Shift into 1st gear.
- Open the throttle a little, and start to let out the clutch lever very slowly.
- As the clutch starts to engage, open the throttle a little more, giving the engine just enough fuel to keep it from stalling.


NOTE

 The motorcycle is equipped with a side stand switch. This switch is designed so that the engine does not

start if the transmission is in gear and the side stand is down.

Shifting Gears

- Close the throttle while pulling in the clutch lever.
- Shift into the next higher or lower gear.



- Open the throttle part way, while releasing the clutch lever.
- For smooth riding, each gear position should cover the proper rate of speed shown in the table.

Downshifting to a lower gear at high speed causes engine rpm to increase excessively, potentially damaging the engine and it may also cause the rear wheel to skid and cause an accident. Downshifting should be done below the vehicle speeds for each gear shown in the table.

A. Shift Pedal

Vehicle speed when shifting

Shifting up	km/h (mph)
$1st \rightarrow 2nd$	15 (9)
$2nd \rightarrow 3rd$	25 (15)
$3rd \rightarrow 4th$	35 (21)
4th \rightarrow 5th	45 (27)
5th \rightarrow 6th	55 (34)

Shifting down	km/h (mph)
6th \rightarrow 5th	30 (19)
5th \rightarrow 4th	25 (15)
4th \rightarrow 3rd	20 (12)
$\mathbf{3rd} \rightarrow \mathbf{2nd}$	15 (9)
$2nd \rightarrow 1st$	15 (9)

NOTE

○ The transmission is equipped with a positive neutral finder. When the motorcycle is standing still, the transmission cannot be shifted past neutral from 1st gear. To use the positive neutral finder, shift down to 1st gear, then lift up on the shift pedal while standing still. The transmission will shift only into neutral.


Braking

- Close the throttle completely, leaving the clutch engaged (except when shifting gears) so that the engine will help slow down the motorcycle.
- Shift down one gear at a time so that you are in 1st gear when you come to a complete stop.
- When stopping, always apply both brakes at the same time. Normally


the front brake should be applied a little more than the rear. Shift down or fully disengage the clutch as necessary to keep the engine from stalling.

- Never lock the brakes, or it will cause the tires to skid. When turning a corner, it is better not to brake at all. Reduce your speed before you get into the corner.
- For emergency braking, disregard downshifting, and concentrate on applying the brakes as hard as possible without skidding.
- Even in motorcycles equipped with ABS, braking during cornering may cause wheel slip. When turning a corner, it is better to limit braking to

the light application of both brakes or not to brake at all. Reduce your speed before you get into the corner.



A. Front Brake Lever



A. Rear Brake Pedal

Anti-lock Brake System (ABS)

(only on ABS model)

ABS is designed to help prevent the wheels from locking up when the brakes are applied hard while running straight. The ABS automatically regulates brake force. Intermittently gaining gripping force and braking force helps

HOW TO RIDE THE MOTORCYCLE 91

prevent wheel lock-up and allows stable steering control while stopping.

Brake control function is identical to that of a conventional motorcycle. The brake lever is used for the front brake and the brake pedal for the rear brake.

Although the ABS provides stability while stopping by preventing wheel lock-up, remember the following characteristics:

- To apply the brake effectively, use the front brake lever and rear brake pedal simultaneously in the same manner as conventional motorcycle brake system.
- ABS cannot compensate for adverse road conditions, misjudgment or improper application of brakes. You must take the same care as with motorcycles not equipped with ABS.
- ABS is not designed to shorten the braking distance. On loose, uneven or downhill surfaces, the stopping

distance of a motorcycle with ABS may be longer than that of an equivalent motorcycle without ABS. Use special caution in such areas.

- ABS will help prevent wheel lock-up when braking in a straight line, but it cannot control wheel slip which may be caused by braking during cornering. When turning a corner, it is better to limit braking to the light application of both brakes or not to brake at all. Reduce your speed before you get into the corner.
- Same as conventional brake system, an excessive sudden braking may cause wheel lock up that makes it harder to control a motorcycle.
- During braking, ABS will not prevent the rear wheel lifting.

AWARNING

ABS cannot protect the rider from all possible hazards and is not a substitute for safe riding practices. Be aware of how the ABS system operates and its limitations. It is the rider's responsibility to ride at appropriate speeds and manner for weather, road surface and traffic conditions.

• The computers integrated in the ABS compare vehicle speed with wheel speed. Since non-recommended tires can affect wheel speed, they may confuse the computers, which can extend braking distance.

A WARNING

Use of non-recommended tires may cause malfunctioning of ABS and can lead to extended braking distance. The rider could have an accident as a result. Always use recommended standard tires for this motorcycle.

NOTE

- O When the ABS is functioning, you may feel a pulsing in the brake lever or pedal. This is normal. You need not suspend applying brakes.
- ABS does not function at speeds of approx. 5 km/h (3.1 mph) or below.
- ABS does not function if the battery is discharged. When riding with an insufficiently charged battery, ABS may not function. Keep the battery in good condition according to

HOW TO RIDE THE MOTORCYCLE 93

the "Battery Maintenance" section in the MAINTENANCE AND ADJUST-MENT chapter.

Stopping the Engine

- Close the throttle completely.
- Shift the transmission into neutral.
- Turn the ignition key to "OFF."
- Support the motorcycle on a firm, level surface with the side stand.
- Lock the steering.

Stopping the Motorcycle in an Emergency

Your Kawasaki Motorcycle has been designed and manufactured to provide you optimum safety and convenience. However, in order to fully benefit from Kawasaki's safety engineering and craftsmanship, it is essential that

you, the owner and operator, properly maintain your motorcycle and become thoroughly familiar with its operation. Improper maintenance can create a dangerous situation known as throttle failure. Two of the most common causes of throttle failure are:

- 1. An improperly serviced or clogged air cleaner may allow dirt and dust to enter the throttle body and stick the throttle open.
- 2. During removal of the air cleaner, dirt is allowed to enter and jam the fuel injection system.

In an emergency situation such as throttle failure, your vehicle may be stopped by applying the brakes and disengaging the clutch. Once this stopping procedure is initiated, the engine stop switch may be used to stop the engine. If the engine stop switch is used, turn off the ignition switch after stopping the motorcycle.

Parking

🛦 warning

Operating or parking the vehicle near flammable materials can cause a fire, and can result in property damage or severe personal injury.

Do not idle or park your vehicle in an area where tall or dry vegetation, or other flammable materials could come into contact with the muffler or exhaust pipe.

The engine and exhaust system get extremely hot during normal operation and can cause serious burns.

Never touch a hot engine, exhaust pipe, or muffler during operation or after stopping the engine.

- Shift the transmission into neutral and turn the ignition key to "OFF."
- Support the motorcycle on a firm, level surface with the side stand.

NOTICE

Do not park on a soft or steeply inclined surface, or the motorcycle may fall over.

 If parking inside a garage or other structure, be sure it is well ventilated

HOW TO RIDE THE MOTORCYCLE 95

and the motorcycle is not close to any source of flame or sparks; this includes any appliance with a pilot light.

Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns. Turn the ignition switch off. Do not smoke. Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

• Lock the steering to help prevent theft.

96 MAINTENANCE AND ADJUSTMENT MAINTENANCE AND ADJUSTMENT

The maintenance and adjustments outlined in this chapter must be carried out in accordance with the Daily Checks and Periodic Maintenance to keep the motorcycle in good running condition and to reduce air pollution. The initial maintenance is vitally important and must not be neglected.

Failure to perform these checks or to correct a problem before operation may result in serious damage or an accident. Always perform daily checks before operation.

With a basic knowledge of mechanics and the proper use of tools, you should be able to carry out many of the maintenance items described in this chapter. If you lack proper experience or doubt your ability, all adjustments, maintenance, and repair work should be completed by a qualified technician.

Please note that Kawasaki cannot assume any responsibility for damage resulting from incorrect or improper adjustment made by the owner.

A DANGER

Exhaust gas contains carbon monoxide, a colorless, odorless poisonous gas. Inhaling carbon monoxide can cause serious brain injury or death. DO NOT run the engine in enclosed areas. Operate only in a well-ventilated area.

A WARNING

The cooling fan spins at high speed and can cause serious injuries. Keep your hands and clothing away from the cooling fan blades at all times.

NOTE

○ If a torque wrench is not available, the maintenance items which require a specific torque value should be serviced by an authorized Kawasaki dealer.

Daily Checks

Check the following items each day before you ride. The time required is minimal, and habitual performance of these checks will help ensure you a safe, reliable ride. If any irregularities are found during these checks, refer to the MAINTENANCE AND ADJUSTMENT chapter or see your dealer for the action required to return the motorcycle to a safe operating condition.

Operation F				
Fuel				
Adequate supply in tank, no leaks	-			
Engine oil				
Oil level between level lines	106			
Tires				
Air pressure (when cold), install the air valve cap	138			
Tire wear	139			
Drive chain				
Slack	124			
Lubricate if dry	124			

Operation	See Page	
Bolts, nuts and fasteners		
Check for loose and/or missing bolts, nuts and fasteners	-	
Steering		
Action smooth but not loose from lock to lock	-	
No binding of control cables	-	
Brakes		
Brake pad wear	130	
Brake fluid level	129	
No brake fluid leakage	-	
Throttle		
Throttle grip free play	119	
Clutch		
Clutch lever free play	123	
Clutch lever operates smoothly	-	
Coolant		
No coolant leakage	-	

Operation	See Page
Coolant level between level lines (when engine is cold)	113
Electrical equipment	
All lights (head, city, tail/brake, turn signal, license plate, warning/indicator) and horn work	-
Engine stop switch	
Stops engine	-
Side stand	
Return to its fully up position by spring tension	-
Return spring not weak or not damaged	-
Rear view mirrors	
Rear view sight	-

Periodic Maintenance

- *A: Service at number of years shown or indicated odometer reading intervals, whichever comes first.
- *B: For higher odometer readings, repeat at the frequency interval established here.
- *C: Service more frequently when operating in severe conditions: dusty, wet, muddy, high speed, or frequent starting/stopping.
- *D: California model only
- O: Emission Related Item
- Q: Inspection
- Change or Replace
 - : Lubrication

- Q: I
- Dealer Inspection
- Dealer Change or Replace
 - : Dealer Lubrication

		year					g (*B) mile)	See
	Items	(*A)	1 (0.6)	6 (3.8)	12 (7.6)	18 (11.4)	24 (15.2)	Page
0	Air cleaner element (*C)	£:2			Q		Q	115
0	Idle speed		q		q		Q	121
0	Throttle control system (play, smooth return, no drag)	Q :1	Q		q		q	119
0	Engine vacuum synchronization				Q		Q	-
	Fuel system	Q:1	Q		Q		Q	-
	Fuel filter						G	_
	Fuel hose	6:5						-
0	Evaporative emission control system (*D)		Q	Q	Q	Q	Q	_
	Coolant level		q		q		Q	113
	Cooling system	Q:1	Q		Q		Q	_

		year				Readin 1 000	g (*B) mile)	See
	Items	(*A)	1 (0.6)	6 (3.8)	12 (7.6)	18 (11.4)	24 (15.2)	Page
	Coolant, water hose and O-ring	©:3	 every 36 000 km (22 500 mile) 					_
0	Valve clearance				Q		Q	_
0	Air suction system				Q		Q	-
	Clutch operation (play, engagement, disengagement)		Q		Q		q	122
	Engine oil (*C) and oil filter	G 1	9		Ð		9	107
	Tire air pressure	Q :1			Q		q	138
	Wheel and tire	Q :1			Q		Q	138
	Wheel bearing damage	Q:1			Q		Q	-
	Spoke tightness and rim runout		Q	Q	Q	Q	Q	_

	year					g (*B) mile)	See
Items	(*A)	1 (0.6)	6 (3.8)	12 (7.6)	18 (11.4)	24 (15.2)	Page
Drive chain lubrication condition (*C)		Q	every	600 k	m (400) mile)	124
Drive chain slack (*C)		Q : every 1 000 km (600 mile)					124
Drive chain wear (*C)				Q		Q	_
Drive chain guide wear				Q		Q	-
Brake system	Q:1	Q		Q		Q	-
Brake operation (effectiveness, play, no drag)	Q :1	Q		Q		Q	_
Brake fluid level	Q :1	q		q		q	129
Brake fluid (front and rear)	G:2					Ð	_
Brake hose	6						_

		year				Readin : 1 000		See
	Items	(*A)	1 (0.6)	6 (3.8)	12 (7.6)	18 (11.4)	24 (15.2)	Page
	Rubber parts of brake master cylinder and caliper	G:4	 every 48 000 km (30 000 mile) 					_
	Brake pad wear (*C)			q	Q	Q	q	130
	Brake light switch operation		q	Q	Q	q	q	131
	Suspension system	Q:1			Q		Q	-
	Lubrication of rear suspension						Ş	-
	Steering play	Q:1	Q		Q		Q	_
	Steering stem bearings	> :2					Ş	-
	Electrical system	Q:1			Q		Q	_
0	Spark plug				G		B	_

	year	Odometer Reading (*B) × 1 000 km (× 1 000 mile)					See
Items		1 (0.6)	6 (3.8)	12 (7.6)	18 (11.4)	24 (15.2)	Page
Chassis parts	P			P		P	_
Condition of bolts, nuts and fasteners		Q		Q		Q	—

Engine Oil


Oil Level Inspection

- If the engine is cold, start the engine and run it for several minutes at idle speed.
- Stop the engine, then wait several minutes until the oil settles.

NOTICE

Racing the engine before the oil reaches every part can cause engine seizure.


• Check the engine oil level through the oil level inspection window. With the motorcycle held level, the oil level should come up between the upper and lower level lines next to the oil level inspection window.



- A. Oil Level Inspection Window
- B. Oil Filler Cap
- C. Upper Level Line
- **D. Lower Level Line**
- If the oil level is too high, remove the excess oil through the oil filler opening using a syringe or some other suitable device.
- If the oil level is too low, add oil to reach the correct level. Use the same type and brand of oil that is already in the engine.


Oil and/or Oil Filter Change

• Remove the lower fairing bolts and collars.




A. Lower Fairing Bolts and Collars

Pull the right lower fairing outward to clear the projection, and remove the right lower fairing.



- A. Projection
- B. Right Lower Fairing
- Warm up the engine thoroughly, and then stop it.
- Place an oil pan beneath the engine.
- Remove the engine oil drain bolt and gasket.

Engine oil is a toxic substance. Dispose of used oil properly. Contact your local authorities for approved disposal methods or possible recycling.




A. Engine Oil Drain Bolt B. Gasket

- Let the oil completely drain with the motorcycle perpendicular to the ground.
- If the oil filter is to be replaced, remove the oil filter and replace it with a new one.


NOTE

 If a torque wrench or required Kawasaki special tool is not available, this item should be serviced by an authorized Kawasaki dealer.



A. Oil Filter

• Apply a thin film of oil to the gasket and tighten the oil filter to the specified torque.



A. Gasket

• Install the drain bolt with a new gasket. Tighten it to the specified torque.

NOTE

○ Replace the gasket with a new one.

Tightening Torque

Oil Filter:

17.5 N·m (1.78 kgf·m, 12.9 ft·lb)

Engine Oil Drain Bolt:

30 N·m (3.1 kgf·m, 22 ft·lb)

• Fill the engine up to the upper level line with a good quality engine oil specified in the table.

Recommended Engine Oil

Туре:
Kawasaki Performance 4-Stroke
Motorcycle Oil*
Kawasaki Performance 4-Stroke
Semi-Synthetic Oil*
Kawasaki Performance 4-Stroke Full
Synthetic Oil*
or other 4-stroke oils with API SG, SH,
SJ, SL or SM with JASO MA, MA1 or
MA2 rating
Viscosity:
SAE 10W-40

*Kawasaki Performance Oils and Lubricants have been specifically engineered for your vehicle. Consistent use of these products meets or exceeds warranty and service requirements and can help to extend the life of your Kawasaki.

NOTE

O Do not add any chemical additive to the oil. Oils fulfilling the above requirements are fully formulated and provide adequate lubrication for both the engine and the clutch.

Engine Oil Capacity

2.0 L (2.1 US qt)


[when filter is not removed]

2.2 L (2.3 US qt)


[when filter is removed]

MAINTENANCE AND ADJUSTMENT 111


Although 10W-40 engine oil is the recommended oil for most conditions, the oil viscosity may need to be changed to accommodate atmospheric conditions in your riding area.



- Start the engine.
- Check the oil level and oil leakage.
- Insert the projection of the right lower fairing into the grommet.



- A. Projection
- B. Grommet
- C. Right Lower Fairing
- Tighten the lower fairing bolts with the collars to specified torque.



A. Lower Fairing Bolt (Upper) and Collar B. Lower Fairing Bolts (Lower) and Collars

Tightening Torque

Lower Fairing Bolts (Lower)

8.8 N·m (0.90 kgf·m, 78 in·lb)


Lower Fairing Bolt (Upper)

4.4 N·m (0.45 kgf·m, 39 in·lb)

Coolant

Coolant Level Inspection

- Position the motorcycle so that it is perpendicular to the ground.
- Check the coolant level through the coolant level gauge on the reserve tank located in right middle fairing. The coolant level should be between the F (Full) and L (Low) level lines.



A. F (Full) Level Line B. L (Low) Level Line C. Reserve Tank

NOTE

- Check the level when the engine is cold (room or atmospheric temperature).
- If the amount of coolant is insufficient, add coolant into the reserve tank.

Coolant Filling

• Remove the cap from the reserve tank and add coolant through the filler opening to the F (Full) level line.



A. Reserve Tank Cap

NOTE

 In an emergency you can add water alone to the coolant reserve tank, however it must be returned to the correct mixture ratio by the addition of antifreeze concentrate as soon as possible.

NOTICE

If coolant must be added often, or the reserve tank completely runs dry, there is probably leakage in the system. Have the cooling system inspected by your authorized Kawasaki dealer.

Coolant Change

Have the coolant changed by an authorized Kawasaki dealer. Coolant Requirement

A WARNING

Coolant containing corrosion inhibitors for aluminum engines and radiators include harmful chemicals for human body. Drinking coolant can result in serious injury or death. Use coolant in accordance with the instructions of the manufacturer.

Use a permanent type of antifreeze (soft water and ethylene glycol plus corrosion and rust inhibitor chemicals for aluminum engines and radiators) in the cooling system. On the mixture ratio of coolant, choose the suitable one referring to the relation between freezing point and strength directed on the container.

NOTICE

If hard water is used in the system, it causes scale accumulation in the water passages, and considerably reduces the efficiency of the cooling system.

NOTE


○ A permanent type of antifreeze is installed in the cooling system when shipped. It is mixed at 50% and has the freezing point of −35°C (−31°F).

Air Cleaner

Air Cleaner Element Removal


- Remove the seat (see Seat section in the GENERAL INFORMATION chapter).
- Remove the air cleaner element cap screws.

• Remove the air cleaner cap.




A. Air Cleaner Element Cap Screws B. Air Cleaner Element Cap

• Pull out the air cleaner element from the air cleaner housing.



A. Air Cleaner Element

• Remove the air cleaner element from the frame.



- A. Air Cleaner Element B. Frame
- Put a clean, lint-free towel into the air cleaner housing to keep dirt or other foreign material from entering.
- Inspect the element material for damage. If any part of the element is damaged, the element must be replaced.

If dirt or dust is allowed to pass through into the throttle body assembly, the throttle may become stuck, possibly causing accident. Be sure to keep the dust from entering during cleaning.

NOTICE

If dirt gets through into the engine, excessive engine wear and possibly engine damage will occur.

Air Cleaner Element Cleaning

- Clean the element in a bath of a high flash-point solvent.
- Squeeze it dry in a clean towel. Do not wring the element or blow it dry; the element can be damaged.

- Check the element for visible damage.
- If element is damaged, replace it.
- After cleaning, saturate the element with a high-quality foam-air-filter oil, squeeze out the excess oil, then wrap it in a clean towel and squeeze it as dry as possible.
- Be careful not to tear the element.

A WARNING

Gasoline and low flash-point solvents are extremely flammable and may explode, causing severe burns. Do not use gasoline or a low flash-point solvent to clean the element. Clean the element in a well-ventilated area. Be sure there are no sparks or flame in the work area, including any appliance with a pilot light.

Air Cleaner Element Installation

• The removed parts installation is performed in the reverse order of removal.

Tightening Torque

Air Cleaner Element Cap Screws


4.2 N·m (0.43 kgf·m, 37 in·lb)

NOTE

 If a torque wrench is not available, this item should be serviced by an authorized Kawasaki dealer.

Oil Draining

 Inspect the transparent drain cap located the left lower end of the air cleaner housing to see if any oil has run down.



- A. Transparent Drain Cap B. Clamp
- If there is any oil in the drain cap, remove the clamp and drain cap, and drain the oil.

Oil on tires will make them slippery and can cause an accident and injury. Be sure to install the drain cap to the air cleaner housing after draining.


Throttle Control System

Throttle Grip

Throttle Grip Free Play Inspection

- Check that the throttle grip moves smoothly from full open to close, and the throttle closes quickly and completely by the return spring in all steering positions.
- If the throttle grip does not return properly, have the throttle control system checked by an authorized Kawasaki dealer.

• Check the throttle grip free play by turning back and forth.



A. Throttle Grip B. Throttle Grip Free Play


Throttle Grip Free Play

 $2\sim3$ mm (0.08 ~0.12 in.)

• If there is improper play, adjust it.

Throttle Grip Free Play Adjustment

- Loosen the locknuts at the upper end of the throttle cables.
- Turn both throttle cable adjuster to give the throttle grip plenty of play.
- Turn the decelerator cable adjuster until there is no play when the throttle grip is completely closed.
- Tighten the locknut.
- Turn the accelerator cable adjuster until of 2 ~ 3 mm (0.08 ~ 0.12 in.) of throttle grip play is obtained.
- Tighten the locknut.



- A. Locknuts
- **B.** Decelerator Cable Adjuster
- C. Accelerator Cable Adjuster
- With the engine idling, turn the handlebars to each side. If handlebars movement changes the idle speed, the throttle cables may be improperly adjusted or incorrectly routed, or they may be damaged. Be sure to correct any of these conditions before idling.

A WARNING

Operation with improperly adjusted, incorrectly routed, or damaged cables could result in an unsafe riding condition. Be sure the control cables are adjusted and routed correctly, and are free from damage.

Idle Speed

Idle Speed Adjustment

- Start the engine, and warm it up thoroughly.
- Adjust the idle speed by turning the idle adjusting screw.

NOTE

 While the engine is cold, the fast idle system automatically raises the engine idling speed.

Idle Speed

1 250 ~ 1 350 r/min (rpm)



A. Idle Adjusting Screw

- Open and close the throttle a few times to make sure that the idle speed does not change. Readjust if necessary.
- With the engine idling, turn the handlebars to each side. If handlebars movement changes the idle speed,

the throttle cables may be improperly adjusted or incorrectly routed, or they may be damaged. Be sure to correct any of these conditions before riding.

A WARNING

Operation with damaged cables could result in an unsafe riding condition. Replace damaged control cables before operation.


Clutch

Clutch Operation Inspection

- Check that the clutch lever operates properly and that the inner cable slides smoothly. If there is any irregularity, have the clutch cable checked by an authorized Kawasaki dealer.
- Check the clutch lever free play.

Clutch Lever Free Play

2 ~ 3 mm (0.08 ~ 0.12 in.)



- A. Adjuster
- B. Locknut
- C. Clutch Lever Free Play
- If the free play is incorrect, adjust the clutch lever free play as follows.

Clutch Lever Free Play Adjustment

 Loosen the locknut, and turn the adjuster so that the clutch lever will have the specified free play.

A WARNING

Excess clutch lever free play could prevent clutch disengagement and cause a crash resulting in serious injury or death. When adjusting the clutch lever free play, be sure the upper end of the clutch outer cable is fully seated in its fitting so that it doesn't slip into place later and create excessive free play.

• If it cannot be done, have the clutch cable adjusted by an authorized Kawasaki dealer.

NOTE

○ After the adjustment is made, start the engine and check that the clutch does not slip and that it releases properly.

Drive Chain


Drive Chain Lubrication

Lubrication is necessary after riding through rain or on wet roads, or any time that the chain appears dry.

Use a lubricant for sealed chains to prevent deterioration of chain seals. If the chain is especially dirty, clean it using a cleaner for sealed chains following the instructions supplied by the chain cleaner manufacturer.

• Apply lubricant to the sides of the rollers so that it will penetrate to the rollers and bushings. Apply lubricant to the seals so that the seals will be

coated with lubricant. Wipe off any excess lubricant.




• Wipe off any lubricant that gets on the tire surface.

Drive Chain Slack Inspection

- Set the motorcycle up on its side stand.
- Clean the chain if it is dirty, and lubricate it if it appears dry.
- Rotate the rear wheel to find the position where the chain is tightest, and

measure the maximum chain slack by pulling up and pushing down the chain midway between the engine sprocket and rear wheel sprocket.



A. Chain Slack


• If the drive chain is too tight or too loose, adjust it so that the chain slack is within the standard value.

Drive Chain Slack

Standard: 25 ~ 35 mm (1.0 ~ 1.4 in.)


Drive Chain Slack Adjustment

- Loosen the left and right chain adjuster locknuts.
- Remove the cotter pin, and loosen the axle nut.



- A. Axle Nut
- **B.** Cotter Pin
- C. Adjuster
- D. Locknut
- If the chain is too loose, turn in the left and right chain adjusters evenly.

If the chain is too tight, turn out the left and right chain adjusters evenly.
Turn both chain adjusters evenly until the drive chain has the correct amount of slack. To keep the chain and wheel properly aligned, the notch on the left wheel alignment indicator should align with the same swingarm mark that the right wheel alignment indicator notch aligns with.



- A. Marks
- **B. Notch**
- **C. Wheel Alignment Indicator**
- D. Adjuster
- E. Locknut

NOTE

 Wheel alignment can also be checked using the straightedge or string method.

Misalignment of the wheel will result in abnormal wear, and may result in an unsafe riding condition. Align the rear wheel using the marks on the swingarm or measuring the distance between the center of the axle and swingarm pivot.

- Tighten both chain adjuster locknuts.
- Tighten the axle nut to the specified torque.

Tightening Torque

Axle Nut:


98 N·m (10 kgf·m, 72 ft·lb)

NOTE

 If a torque wrench is not available, this item should be serviced by an authorized Kawasaki dealer.

MAINTENANCE AND ADJUSTMENT 127

- Rotate the wheel, measure the chain slack again at the tightest position, and readjust if necessary.
- Install a new cotter pin through the axle nut and axle, and spread its ends.



A. Cotter Pin


NOTE

 When inserting the cotter pin, if the slots in the nut do not align with the cotter pin hole in the axle shaft,

tighten the nut clockwise up to the next alignment.

○ It should be within 30 degrees.

 Loosen once and tighten again when the slot goes past the nearest hole.



A. Turn Clockwise

A loose axle nut can lead to an accident resulting in serious injury or death. Tighten the axle nut to the proper torque and install a new cotter pin.

• Check the rear brake (see Brakes section).

Brakes


If you feel there is something wrong when applying the brakes, have the brake system checked by an authorized Kawasaki dealer immediately.

A WARNING


Air in the brake lines diminish braking performance and can cause an accident resulting in injury or death. If the brake lever or pedal feels mushy when it is applied, there might be air in the brake lines or the brake may be defective. Have the brake checked immediately by an authorized Kawasaki dealer.

Brake Fluid Level Inspection

• With the front brake fluid reservoir held horizontal, the brake fluid level must be above the lower level line.



- A. Front Brake Fluid Reservoir B. Lower Level Line
- With the rear brake fluid reservoir held horizontal, the brake fluid level must be kept between the upper and lower level lines.




- A. Rear Brake Fluid Reservoir B. Upper Level Line
- C. Lower Level Line
- If the fluid level is lower than the lower level line it may indicate that the fluid is leaking. In this case, have the brake system inspected by an authorized Kawasaki dealer.


Brake Pad Wear Inspection

Inspect the brakes for wear. For each front and rear disc brake caliper, if the

thickness of either pad lining is less than 1.5 mm (0.06 in.), replace both pads in the caliper as a set. Pad replacement should be done by an authorized Kawasaki dealer.



A. Front Brake Pads B. Lining Thickness C. 1.5 mm (0.06 in.)



A. Rear Brake Pads B. Lining Thickness C. 1.5 mm (0.06 in.)


Brake Light Switches

Brake Light Switch Inspection

- Turn the ignition switch on.
- The brake light should go on when the front brake is applied.

MAINTENANCE AND ADJUSTMENT 131

- If it does not, ask your authorized Kawasaki dealer to inspect the front brake light switch.
- Check the operation of the rear brake light switch by depressing the brake pedal. The brake light should go on after the proper pedal travel.



A. Brake Pedal


- B. 10 mm (0.39 in.)
- If the light does not come on, adjust the rear brake light switch.

Brake Pedal Travel

10 mm (0.39 in.)


Brake Light Switch Adjustment

• Remove the bolts and collars.




A. Bolts and Collars

• Pull the right side cover outward to clear the projections, and remove the right side cover.



- A. Projections B. Right Side Cover
- To adjust the rear brake light switch, move the switch up or down by turning the adjusting nut.




- A. Rear Brake Light Switch
- **B. Adjusting Nut**
- C. Lights sooner
- **D. Lights later**

NOTICE

To avoid damaging the electrical connections inside the switch, be sure that the switch body does not turn during adjustment.

MAINTENANCE AND ADJUSTMENT 133

• Insert the projections of the right side cover into the grommets.



- A. Projections
- **B. Grommets**
- C. Right Side Cover
- Tighten the bolts with the collars.

Suspension System

Front Fork

NOTICE

After riding on the normal road, the unpaved road and in the rainy weather, clean off any dirt (grit, mud or insect etc.) that stuck to inner tube before it hardens. If the motorcycle keeps running with the dirt stuck to the inner tube, the oil seal will be damaged and it causes the oil leak.

Rear Shock Absorber

Spring Preload Adjustment

The spring preload adjuster on the rear shock absorber has 5 positions. **Standard**


3rd position

Remove the bolts and collars.




A. Bolts and Collars


• Pull the left side cover outward to clear the projections, and remove the left side cover.



- A. Projections B. Left Side Cover
- In accordance with the setting table, turn the preload adjuster with the wrench from the tool kit.



- A. Spring Preload Adjuster
- B. Wrench
- C. Handle
- Insert the projections of the left side cover into the grommets.



- A. Projections
- B. Grommets
- C. Left Side Cover

• Tighten the bolts with the collars.

Setting Table

Rear Shock Absorber Spring Preload Setting

1 8			
	Softest setting limit	Standard	Hardest setting limit
Adjuster Position	1st	3rd	5th
Spring Action	Weak	\longleftrightarrow	Strong
Setting	Soft	\longleftrightarrow	Hard
Load	Light	\longleftrightarrow	Heavy
Road	Good	\longleftrightarrow	Bad
Speed	Low	$\leftarrow \rightarrow$	High

Wheels

Tire Pressure Inspection

- Remove the air valve cap.
- Check the tire pressure often, using an accurate gauge.
- Make sure to install the air valve cap securely.

NOTE

- O Measure the tire pressure when the tires are cold (that is, when the motorcycle has not been ridden more than 1.6 km (1 mile) during the past 3 hours).
- O Tire pressure is affected by changes in ambient temperature and altitude, and so the tire pressure should be checked and adjusted when your riding involves wide variations in temperature or altitude.



A. Tire Pressure Gauge

Tire Air Pressure (when cold)


Front	200 kPa (2.00 kgf/cm², 28 psi)
Rear	225 kPa (2.25 kgf/cm², 32 psi)

Tire Wear, Damage

As the tire tread wears down, the tire becomes more susceptible to puncture and failure. An accepted estimate is that 90% of all tire failures occur during the last 10% of tread life (90% worn). So it is false economy and unsafe to use the tires until they are bald.

Tire Wear Inspection

• Measure the depth of the tread with a depth gauge, and replace any tire that has worn down to the minimum allowable tread depth.




A. Tire Depth Gauge

Minimum Tread Depth

Front	_	1 mm (0.04 in.)
Deer	Under 130 km/h (80 mph)	2 mm (0.08 in.)
Rear	Over 130 km/h (80 mph)	3 mm (0.12 in.)

• Visually inspect the tire for cracks and cuts, replacing the tire in case of bad damage. Swelling or high spots indicate internal damage, requiring tire replacement.



- A. Crack or Cut
- B. Nail
- C. Swelling or High Spot
- D. Stone
- Remove any imbedded stones or other foreign particles from the tread.

NOTE

• Have the wheel balance inspected whenever a new tire is installed.

AWARNING

Tires that have been punctured and repaired do not have the same capabilities as undamaged tires and can suddenly fail, causing an accident resulting in serious injury or death. Replace damaged tires as soon as possible. To ensure safe handling and stability, use only the recommended standard tires for replacement, inflated to the standard pressure. If it is necessary to ride on a repaired tire, do not exceed 100 km/h (60 mph) until the tire is replaced.

NOTE

 When operating on public roadways, keep maximum speed under traffic law limits. Standard Tire (Tube-type)

Front	Make, Type: IRC, GP-210F Size:
	100/90-19M/C 57S
Rear	Make, Type: IRC, GP-210R Size: 130/80-17M/C 65S

Mixing tire brands and types can adversely affect handling and cause an accident resulting in injury or death. Always use the same manufacturer's tires on both front and rear wheels. MAINTENANCE AND ADJUSTMENT 141

New tires are slippery and may cause loss of control and injury. A break-in period of 160 km (100 miles) is necessary to establish normal tire traction. During break-in, avoid sudden and maximum braking and acceleration, and hard cornering.

Battery

The battery installed in this motorcycle is a sealed type, so it is not necessary to check the battery electrolyte level or add distilled water.

NOTICE

Never remove the sealing strip, or the battery can be damaged. Do not install a conventional battery in this motorcycle, or the electrical system cannot work properly.

Make	Siam Furukawa
Туре	FTX9-BS

Battery Maintenance

It is the owner's responsibility to keep the battery fully charged. Failure to do so can lead to battery failure and leave you stranded.

If you are riding your vehicle infrequently, inspect the battery voltage weekly using a voltmeter. If it drops below 12.6 volts, the battery should be charged using an appropriate charger (check with your Kawasaki dealer). If you will not be using the motorcycle for longer than two weeks, the battery should be charged using an appropriate charger. Do not use an automotive-type quick charger that may overcharge the battery and damage it.

NOTE

Cleaving the battery connected causes the electrical components (clock etc.) to make the battery discharged, resulting the over discharge of the battery. In this case, the repair or replacement of the battery is not included in the warranty. If you do not drive for four weeks or more, disconnect the battery from the vehicle.

Kawasaki-recommended chargers are:

Battery Mate 150-9 OptiMate 4 Yuasa MB-2040/2060 Christie C10122S If the above chargers are not available, use equivalent one.

For more details, ask your Kawasaki dealer.

Battery Charging

- Charge the battery following the instructions of your battery charger.
- The charger will keep the battery fully charged until you are ready to reinstall the battery in the motorcycle (see Battery Installation).

A DANGER


- Battery acid generates hydrogen gas which is flammable and explosive under certain conditions. It is present within a battery at all times, even in a discharged condition. Keep all flames and sparks (cigarettes) away from the battery.
- Wear eye protection when working with a battery. In the event of battery acid contact with skin, eyes, or clothing, wash the affected areas immediately with water for at least five minutes. Seek medical attention.

A WARNING

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. Wash hands after handling.

Battery Removal

- Make sure the ignition switch is turned off.
- Remove the seat (see Seat section in the GENERAL INFORMATION chapter).
- Disconnect the negative (-) cable from the (-) terminal.
- Slide the red cap from the positive (+) terminal.
- Disconnect the positive (+) cable from the (+) terminal.
- Remove the band.



- A. Red Cap and (+) Terminal B. (-) Terminal C. Band
- Take the battery out of the battery case.
- Clean the battery using a solution of baking soda and water. Be sure that the cable connections are clean.

Battery Installation

• Place the battery on the battery case.

• Connect the positive (+) cable to the (+) terminal, and then connect the negative (-) cable to the (-) terminal.

NOTICE

Installing the negative (-) cable to the (+) terminal of the battery or the positive (+) cable to the (-) terminal of the battery can seriously damage the electrical system.

- Put a light coat of grease on the terminals to prevent corrosion.
- Cover the (+) terminal with the red cap.

MAINTENANCE AND ADJUSTMENT 145

• Install the removed parts.


Headlight

Headlight aiming should be done by an authorized Kawasaki dealer.

Headlight Aiming Adjustment

NOTE

O The left and right adjusters on the headlight can move the direction of the headlight beam to up, down, left and right by turning each adjuster itself as the below table.




- A. Left Adjuster
- B. Right Adjuster
- C. Moving Direction of Headlight Beam
- D. Up
- E. Down
- F. Left
- G. Right

- To move the headlight beam leftward, turn the left adjuster clockwise and turn the right adjuster counterclockwise same number until the beam points straight ahead.
- To move the headlight beam rightward, turn the left adjuster counterclockwise and turn the right adjuster clockwise same number until the beam points straight ahead.
- If not properly adjusted horizontally, the beam will point to one side rather than straight ahead.
- To move the headlight beam upward, turn the both adjusters clockwise same number.
- To move the headlight beam downward, turn the both adjusters counterclockwise same number.

 If adjusted too low, neither low nor high beam will illuminate the road far enough ahead. If adjusted too high, the high beam will fail to illuminate the road close ahead, and the low beam will blind oncoming drivers.

NOTE

 On high beam, the brightest points should be slightly below horizontal. The proper angle is 0.4 degrees below horizontal. This is a 50 mm (2.0 in.) drop at 7.6 m (25 ft) measured from the center of the headlight, with the motorcycle on its wheels and the rider seated.




A. 50 mm (2.0 in.) B. Center of Brightest Spot C. 7.6 m (25 ft) D. Height of Headlight Center

Fuses

Fuses are arranged in the fuse boxes located under the seat. The main fuse is located under the seat. If a fuse fails during operation, inspect the electrical system to determine the cause, and then replace it with a new fuse of proper amperage.


If the fuse fails repeatedly, there is something wrong with the electrical system. Have the motorcycle checked by an authorized Kawasaki dealer.

The main fuse removal should be done by an authorized Kawasaki dealer.



A. Fuse Boxes B. Fuse Box (ABS) C. Main Fuse

Substituting fuses can cause wiring to overheat, catch fire and/or fail. Do not use any substitute for the standard fuse. Replace the blown fuse with a new one of the correct capacity, as specified on the fuse boxes and main fuse.



A. Normal

General Lubrication

Lubricate the points shown below, with either engine oil or regular grease, in accordance with the Periodic Maintenance Chart or whenever the vehicle has been operated under wet or rainy conditions.

Before lubricating each part, clean off any rusty spots with rust remover and wipe off any grease, oil, dirt, or grime.

Apply motor oil to the following pivots

- Side Stand
- Clutch Lever
- Front Brake Lever
- Rear Brake Pedal

Lubricate the following cables with a pressure cable luber

- (K) Clutch Inner Cable
- (K) Throttle Inner Cables

B. Failed

Apply grease to the following points

- (K) Clutch Inner Cable Upper End
- (K) Throttle Inner Cable Upper Ends
 - **(K):** Should be serviced by an authorized Kawasaki dealer.

NOTE

○ After connecting the cables, adjust them.

Cleaning

General Precautions

Frequent and proper care of your vehicle will enhance its appearance, optimize overall performance, and extend its useful life. Covering your vehicle with a high quality, breathable vehicle cover will help protect its finish from harmful UV rays, pollutants, and reduce the amount of dust reaching its surfaces.

Build-up of debris or flammable material in and around the vehicle chassis, engine, and exhaust can cause mechanical problems and increase the risk of fire. When operating the vehicle in conditions that allow debris or flammable material to collect in and around the vehicle, inspect the engine, electrical component and exhaust areas frequently. If debris or flammable materials have collected, park the vehicle outside and stop the engine. Allow the engine to cool, then remove any collected debris. Do not park or store the vehicle in an enclosed space prior to inspecting for build-up of debris or flammable materials.

MAINTENANCE AND ADJUSTMENT 151

- Be sure the engine and exhaust are cool before washing.
- When washing the vehicle, always use a mild neutral detergent and water.
- Avoid applying all harsh chemicals, solvents, degreaser, oil remover, electrical contact cleaner, and household cleaning products such as ammonia-based window cleaners. They will damage or deteriorate painted parts, plastic parts, rubber parts and other synthetic parts including covers and headlight lens.
- Avoid applying degreaser to seals, brake pads, and tires.
- Gasoline, brake fluid, and coolant will damage the finish of painted and plastic surfaces: wash them off immediately.
- Avoid wire brushes, steel wool, and all other abrasive pads or brushes.

• Take care when washing the headlight lens and other plastic parts as they can easily be scratched.

NOTE

- After riding in an area where the roads are salted or near the ocean, immediately wash your vehicle with <u>cold water</u>. Do not use warm water as it accelerates the chemical reaction of the salt. After drying, apply a corrosion protection spray on all metal and chrome surfaces to prevent corrosion.
- Condensation may form on the inside of the headlight lens after riding in the rain, washing the vehicle or humid weather. To remove the moisture, start the engine and turn on the headlight. Gradually the condensation on the inside of the lens will clear off.

Radiator

Clean off any obstructions with a stream of low-pressure water.

NOTICE

Using high-pressure water, as from a car wash facility, could damage the radiator fins and impair the radiator's effectiveness. Do not obstruct or deflect airflow through the radiator by installing unauthorized accessories in front of the radiator or behind the cooling fan. Interference with the radiator airflow can lead to overheating and consequent engine damage.

Matte Paint Parts

• When washing the vehicle, always use a mild neutral detergent and water, or cleaners for matte paint.

- The matte paint effect may be lost when the paint is excessively rubbed.
- If any doubt, consult an authorized Kawasaki dealer.

Plastic Parts

After washing, use a soft cloth to gently dry plastic parts. When dry, treat the headlight lens and other nonpainted plastic parts with an approved plastic cleaner/polisher product.

NOTICE

Plastic parts may deteriorate and break if they come in contact with chemical substances or household cleaning products such as gasoline, brake fluid, window cleaners, thread-locking agents, or other harsh chemicals. If a plastic part comes in contact with any harsh chemical substance, wash it off immediately with water and a mild neutral detergent, and then inspect for damage. Avoid using abrasive pads or brushes to clean plastic parts, as they will damage the part's finish.

Chrome and Aluminum

Chrome and uncoated aluminum parts can be treated with a chrome/aluminum polish. Coated aluminum

should be washed with a mild neutral detergent and finished with a spray polish. Aluminum wheels, both painted and unpainted can be cleaned with special non-acid based wheel spray cleaners.

Leather, Vinyl, and Rubber

If your vehicle has leather accessories, special care must be taken. Use a leather cleaner/treatment to clean and care for leather accessories. Washing leather parts with detergent and water will damage them, shortening their life.

Vinyl parts should be washed with the rest of the vehicle, then treated with a vinyl treatment.

The sidewalls of tires and other rubber components should be treated with a rubber protectant to help prolong their useful life.

Where to be Careful

Avoid spraying water with any great force near the following places.

- Disc brake master cylinder and caliper.
- Under the seat and fuel tank if water gets into the fuse box or battery, it can ground out the spark. When this happens the vehicle will not operate properly and the affected parts must be wiped dry.

NOTICE

Coin operated, high pressure spray washers are not recommended. Water may be forced into bearings and other components causing eventual failure from rust and corrosion. Some soaps are highly alkaline and may leave a residue or cause spotting.

NOTE

 Abrasive cleanser or high pressure washer will damage the surface finish on the bodywork.

Washing Your Vehicle

• Before washing, precautions must be taken to keep water off the following parts.

MAINTENANCE AND ADJUSTMENT 155

Muffler rear opening - cover with a plastic bag.

Ignition switch - cover the keyhole with tape.

- Rinse your vehicle with cold water from a garden hose to remove any loose dirt.
- Mix a mild neutral detergent (designed for motorcycles or automobiles) and water in a bucket. Use a soft cloth or sponge to wash your vehicle.
- After washing, rinse your vehicle thoroughly with clean water to remove any residue (residue from the detergent can damage parts of your vehicle).
- Remove the plastic bag and tape.
- Use a soft cloth to dry your vehicle. As you dry, inspect your vehicle for chips and scratches. Do not let the water air dry as this can damage the painted surfaces.

• Carefully ride your vehicle at a slow speed and apply the brakes several times. This helps dry the brakes

and restores them to normal operating performance.

Storage

Whenever your motorcycle will not be in use for a long period, proper storage is essential.

It consists of checking and replacing missing or worn parts; lubricating parts to ensure that they do not corrode and, in general, preparing the motorcycle so that when the time comes to use it again, it will be in top condition.

See your authorized Kawasaki dealer for this service or do the following.

Preparation for Storage

Make sure the area is well ventilated and free from any source of flame.

A DANGER

Exhaust gas contains carbon monoxide, a colorless, odorless poisonous gas. Inhaling carbon monoxide can cause serious brain injury or death. DO NOT run the engine in enclosed areas. Operate only in a well-ventilated area.

Gasoline is extremely flammable and can be explosive under certain conditions, creating the potential for serious burns.

- Turn the ignition key off.
- Do not smoke.
- Make sure the area is well ventilated and free from any source of flame or sparks; this includes any appliance with a pilot light.

Gasoline is a toxic substance. Dispose of gasoline properly. Contact your local authorities for approved disposal methods.

- Clean the entire vehicle thoroughly.
- Run the engine for about five minutes to warm the oil, shut it off, and drain the engine oil. (see Engine Oil section in the MAINTENANCE AND ADJUSTMENT chapter)

Engine oil is a toxic substance. Dispose of used oil properly. Contact your local authorities for approved disposal methods or possible recycling.

- Put in fresh engine oil.
- Empty the fuel from the fuel tank using a pump or syphon.
- Remove the spark plugs and add fogging oil into the combustion chambers. If the spark plugs cannot be removed, take the motorcycle to an authorized Kawasaki dealer.
- Set the motorcycle on a stand so that both wheels are raised off the ground. (If this cannot be done, put boards under the front and rear wheels to keep dampness away from the tire rubber.)
- Spray oil on all unpainted metal surfaces to prevent rusting. Avoid getting oil on rubber parts or in the brakes.
- Lubricate the drive chain and all the cables.
- Remove the battery, and store it where it will not be exposed to direct sunlight, moisture, or freezing temperatures. During storage it should be given a slow charge (one ampere or less) about once a month. Keep the battery well charged especially during cold weather.
- Tie plastic bag over the muffler to prevent moisture from entering.
- Put a cover over the motorcycle to keep dust and dirt from collecting on it.

Preparation after Storage

- Remove the plastic bag from the muffler.
- Charge the battery if necessary and install the battery in the motorcycle.
- Fill the fuel tank with fresh fuel.
- Check all the points listed in the Daily Checks section.
- Lubricate the pivots, bolts, and nuts.

Troubleshooting Guide

If a Problem Occurs

Performing daily checks and periodic maintenance prevents unexpected troubles from occurring. In case of a breakdown, take emergency measures and contact your Kawasaki dealer to request repair. For safety, inspection and maintenance should be done within your knowledge and ability. If you are not confident in completing an inspection or maintenance, ask an authorized Kawasaki dealer to do the work.

- When carrying out an inspection, follow the precautions below.
- Secure a place where you can work in safety without obstructing traffic around you. Do not carry out any inspection unless it is safe.
- Support the motorcycle on a firm, level surface with the stand.
- The engine and muffler will become hot during operation. To avoid burns etc., do not touch the hot engine or muffler just after the engine has stopped.
- Exhaust gas contains harmful substances such as carbon monoxide. Do not run the engine in an enclosed garage or poorly ventilated area.
- Wait until the engine cools down before carrying out inspection and maintenance or replenishing fuel. Make sure the area is well ventilated and free from any source of flame or sparks. Do not place any appliance with a pilot light nearby.
- If a test ride is needed, ride in a safe area and pay close attention to traffic around you.

When any warning indicators go on or blink, have the motorcycle inspected by an authorized Kawasaki dealer immediately.

If the Engine Does Not Start

When the engine turns over but the engine does not start, inspect as follows.

- Check the fuel level in the fuel tank. If only a small quantity of fuel remains in the bottom, replenish the fuel tank. (Fuel in the tank cannot be completely consumed.)
- Leaving the motorcycle unused for a long time may cause fuel in the tank to deteriorate. In that case, ask an authorized Kawasaki dealer for inspection.
- When the engine warning indicator on the meter goes on and stays on, there may be a problem with the fuel injection system. Ask an authorized Kawasaki dealer for inspection and maintenance.
- The motorcycle is equipped with a vehicle-down sensor which stops the engine automatically when the motorcycle falls down. When the starter button is pressed after the motorcycle has fallen down, the engine does not start. To start the engine, switch the ignition key to the "OFF" position and then back to the "ON" position.

If the engine will not start after completing the above inspection and maintenance, there may be something wrong with another system such as the ignition system. Ask an authorized Kawasaki dealer for inspection and maintenance.

When the starter motor does not rotate, inspect as follows.

- Check the position of the engine stop switch. Push the engine stop switch in the
 - Ω position if it is in the \bowtie position.
- Make sure that the gear position is in the neutral position. If not, shift the transmission into neutral.

• Inspect the fuse condition. If any fuse has blown, replace it with a new one of the same amperage.

Substituting fuses can cause wiring to overheat, catch fire and/or fail. Use only standard fuses of the correct capacity and specifications.

- Check the battery cable connections etc. (see page 144). If necessary, tighten the connecting bolts to securely connect them.
- In case of slow blinking of the turn signal lights, low volume of the horn sound, or when you press the starter button and hear a click but the starter motor does not rotate, battery charging status is not good. Refresh the battery's charge (see page 143) and check if the starter motor rotates.
- Even after a refresh charge, if the starter motor stops rotating the engine properly, the battery may have deteriorated. Have the battery inspected by an authorized Kawasaki dealer.

If the starter motor will not start after completing the above inspection and maintenance, there may be something wrong with another part such as the starter motor. Ask an authorized Kawasaki dealer for inspection and maintenance.

If the Engine Stalls or Runs Poorly

- Check the fuel level in the fuel tank. If only a small quantity of fuel remains, replenish the fuel tank. (Fuel in the tank cannot be completely consumed.)
- Raise the side stand fully up before starting the engine. (If you try to move off with the side stand is still down, the engine will stop.)
- Make sure that correct fuel is used. If not, replace the fuel the correct type (see page 71).
- Due to too much play in the clutch lever, the clutch may not disengage. If there is any problem, adjust the clutch lever free play correctly.
- In case of slow blinking of the turn signal lights, low volume of the horn sound, or when you press the starter button and hear a click but the starter motor does not rotate, the battery is discharged. Check the connections of the battery terminals for looseness (see page 144). If necessary, tighten the bolts to remove the looseness. If the above methods cannot solve the problems, ask an authorized Kawasaki dealer for inspection and maintenance.
- If the warning indicator goes on and coolant temperature warning indicator is displayed, the engine may have overheated. Check the coolant level in the reserve tank after the engine cools down. If the coolant quantity is less than the lower level, replenish the coolant or soft water up to the upper level (see page 113). Ask an authorized Kawasaki dealer to identify the cause of the overheat immediately.
- When the engine warning indicator on the meter goes on and stays on, there is something wrong with the fuel injection system. Ask an authorized Kawasaki dealer for inspection and maintenance.

If the engine stalls after completing the above inspection and maintenance, there may be something wrong with other system. Ask an authorized Kawasaki dealer for inspection and maintenance.

Your Warranty/Owner Satisfaction

Welcome to the Kawasaki family!

Congratulations on buying your Kawasaki vehicle. You've chosen a great, highquality product with state-of-the-art features and built to Kawasaki's high standards. Your satisfaction is important to your authorized Kawasaki dealer and to Kawasaki Motors Corp., U.S.A. Here is some important information regarding your vehicle's limited warranty.

Frequently Asked Questions

What is a Limited Warranty?

The most important thing to know about your warranty is that it protects you from manufacturing defects in material or workmanship during the warranty period. You can find the warranty period in the Kawasaki Limited Warranty Certificate your Kawasaki dealer provided to you at the time of sale. The warranty does not cover the cost of regularly-scheduled maintenance. The warranty also does not apply to the normal wear of items such as tires, brake pads, transmission drive belts, chains, sprockets, etc.

What is the Kawasaki Protection Plus?

Much of the warranty coverage offered by the limited warranty can be extended by purchasing the Kawasaki Protection Plus (KPP). See your Kawasaki dealer or go to Kawasaki.com for more information if you don't already have the KPP.

What Am I Responsible For?

You are responsible for maintaining your vehicle according to the maintenance schedule shown in this owner's manual.

You are responsible for notifying your dealer immediately if there is a problem, and you, as the owner, will need to authorize the dealer to inspect the unit.

You will be responsible for paying for routine maintenance, including the first scheduled service. You can have the required servicing done by your Kawasaki dealer (recommended) or an equally-qualified service facility. You can also do your own maintenance work if you have the proper tools, service references, and mechanical skills. However, if a failure is found to be caused by improper servicing, it would not be covered by the limited warranty.

You may purchase a Kawasaki Service Manual and any necessary special tools directly from your Kawasaki dealer.

You will be responsible for paying for repairs needed because of an accident, to replace worn parts such as tires, chains, brakes, and for repairs needed because of a lack of maintenance, misuse or racing.

Whether you do it yourself or take your vehicle to a Kawasaki dealer, be sure to record your service in the Maintenance Record section of this Owner's Manual. Keep all receipts for the service and/or items necessary to perform the maintenance so that in the event of a failure you can document the service history.

What Are The Dealership's Responsibilities?

Your Kawasaki dealer offers a wide range of services, parts, accessories, and information on your product and on Kawasaki.

Each dealer is independently owned and operated and is responsible for the dealership's operations, its repair, warranty, and service work, and its personnel.

Your dealer is responsible for completing the set up and pre-delivery service of your new Kawasaki vehicle. The dealership should also explain its operation, maintenance, and warranty provisions so you understand them at the time of purchase or at any other time you have questions.

The dealership is responsible for inspecting your Kawasaki vehicle if there is a failure, investigating the cause of the problem, and getting any needed authorization from Kawasaki if the repair is one that will be covered by the limited warranty. The dealership will also file all necessary paperwork. The dealership is responsible for correctly completing any necessary repairs, whether they are covered by the limited warranty or not.

How Do I Get Warranty Service?

If there is a problem with your vehicle within the limited warranty period, you will need to schedule a service appointment and provide any maintenance records to an authorized Kawasaki dealer for inspection and diagnosis. You can go to any Kawasaki dealer for warranty repairs. Your Kawasaki dealer will inspect your vehicle and give you the results of the inspection. The dealer will perform the repairs at no cost to you if it is determined that the problem is covered by the warranty.

Kawasaki will work with your dealer to resolve any warranty issues. No authorization for warranty work can be given until your vehicle has been inspected by a Kawasaki dealer.

What if I am not Satisfied With My Warranty Service?

If you aren't satisfied with your dealership's repair work or operations, it is best to discuss the situation with the appropriate dealership manager. If you have already done this, then contact the dealership's owner or general manager to request a review of the issue.

If you are unable to resolve a problem after consulting with the dealership management and need further assistance, contact Kawasaki Motors Corp., U.S.A. at the address below. Please be certain to provide the model, vehicle identification number (VIN), mileage or hours of use, accessories, dates that events occurred and what action has been taken by both you and your dealer. Include the name and address of the dealership. To assist us in resolving your inquiry, please include copies of related receipts and any other pertinent information including the name of the dealership personnel with whom you have been working. Upon receipt of your correspondence, Kawasaki Motors Corp., U.S.A. will contact the dealership and work with it in resolving your problem.

Want to Contact Kawasaki?

This owner's manual should answer most of your questions about your Kawasaki. Your Kawasaki dealer should either be able to answer any other questions you might have immediately or be able to find the answer for you.

Please send your correspondence to: Consumer Services Kawasaki Motors Corp., U.S.A. P.O. Box 25252 Santa Ana, CA 92799-5252 (949) 460-5688

Environmental Protection

To help preserve the environment, properly discard used batteries, tires, oils and fluids, or other vehicle components that you might dispose of in the future. Consult your authorized Kawasaki dealer or local environmental waste agency for their proper disposal procedure. This also applies to disposal of the entire vehicle at the end of its life.

MAINTENANCE RECORD

Owner Name
Address
Phone Number
Engine Number
Vehicle Number
Key Code
Selling Dealer Name
Phone Number
Warranty Start Date

Note: Keep this information and a spare key in a secure location.

Date	Odometer Reading	Maintenance Performed	Dealer Name	Dealer Address

Date	Odometer Reading	Maintenance Performed	Dealer Name	Dealer Address

Date	Odometer Reading	Maintenance Performed	Dealer Name	Dealer Address

Date	Odometer Reading	Maintenance Performed	Dealer Name	Dealer Address

KLE300BK/CK

* 9 9 9 8 7 - 0 0 8 4 *

Printed in Thailand

Kawasaki Heavy Industries, Ltd. Motorcycle & Engine Company

